



# SYNAPSE

## **ERC108-118**

## **ERS108-118**

Enhanced Rack Controller with optional SNMP agent  
(ERS/ERC108-118) for the SFR08 and SFR18

### **Installation and Operation manual**

# *Synapse*

## **TECHNICAL MANUAL**

ERS108-118

ERC108-118



**Hercules 28**

**NL-5126 RK Gilze**

**The Netherlands**

**Phone: +31 161 850 450**

**Fax: +31 161 850 499**

**E-mail: [Info@axon.tv](mailto:Info@axon.tv)**

**Web: [www.axon.tv](http://www.axon.tv)**



**WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE**

- ALWAYS disconnect your entire system from the AC mains before cleaning any component. The product frame (SFR18, SFR08 or SFR04) must be terminated with three-conductor AC mains power cord that includes an earth ground connection. To prevent shock hazard, all three connections must always be used.
- NEVER use flammable or combustible chemicals for cleaning components.
- NEVER operate this product if any cover is removed.
- NEVER wet the inside of this product with any liquid.
- NEVER pour or spill liquids directly onto this unit.
- NEVER block airflow through ventilation slots.
- NEVER bypass any fuse.
- NEVER replace any fuse with a value or type other than those specified.
- NEVER attempt to repair this product. If a problem occurs, contact your local Axon distributor.
- NEVER expose this product to extremely high or low temperatures.
- NEVER operate this product in an explosive atmosphere.

**Warranty:** Axon warrants their products according to the warranty policy as described in the general terms. That means that Axon Digital Design BV can only warrant the products as long as the serial numbers are not removed.

**Copyright © 2001 – 2014 AXON Digital Design B.V.**

Date created: 15-12-2011

Date last revised: 20-07-2016

**Axon, the Axon logo and Synapse are trademarks of Axon Digital Design B.V.**

This product complies with the requirements of the product family standards for audio, video, audio-visual entertainment lighting control apparatus for professional use as mentioned below.



EN60950	Safety
EN55103-1: 1996	Emission
EN55103-2: 1996	Immunity

Axon Digital Design  
ERS/ERC108-118



Tested To Comply  
With FCC Standards

FOR HOME OR OFFICE USE

This device complies with part 15 of the FCC Rules  
Operation is subject to the following two conditions:  
(1) This device may cause harmful interference, and  
(2) This device must accept any interference received, including interference that may cause undesired operation.

## Table of Contents

<b>Introduction to Synapse</b>	<b>5</b>
An Introduction to Synapse	5
Local Control Panel	5
<b>Unpacking and Placement</b>	<b>6</b>
Unpacking	6
Placing the card	6
<b>A Quick Start</b>	<b>7</b>
Powering-up	7
Changing settings and parameters	7
Front Panel Control	7
Menu Structure Example	9
Introduction to Cortex	9
Download the latest version	10
Minimum system requirements	10
Installation of Cortex	11
Logging on	11
Network adapter	11
Windows firewall	12
<b>The ERS/ERC108-118 Card</b>	<b>13</b>
Introduction	13
Automatic IP Address Configuration	13
Manual IP Address Configuration	13
MAC address	13
<b>Settings Menu</b>	<b>14</b>
Introduction	14
IP_Conf0	14
mIP0	14
mNM0	14
mGW0	14
mPri_DNS	14
mSec_DNS	14
Broadcasts	15
Forwarding0	15
FW0	15
Forwarding1	15
FW1	15
NetwPrefix0	15
ErrorThreshold	15
Redund_Pwr_Test	15
Trap-Dest_0	16
TD_0	16
Trap-Dest_1	16
TD_1	16
NTPServer1	16
NTPServer2	16
NTPOffsetH	16
NTPOffsetM	16
Time_Broadcast	16
USB-Relay_chk	16
Fan_Speed_Control	17
<b>Status Menu</b>	<b>18</b>
Introduction	18
IP_Addr0	18
IP0	18
NM0	18
GW0	18
MAC0	18
Pri_DNS	18
Sec_DNS	18
PSU_Top	18
PSU_Bottom	18
Temp_Left	18
Temp_Right	18
ERC_Temp	18
Temp_Front	19
Left_Fan_Status	19
Right_Fan_Status	19

Front_Fan_Status	19
Fans_PwrStatus	19
Front_PwrStatus	19
SPF_Status	19
SPF_Progress	19
Redund_Ref_Pwr	19
NTP_Status	19
MIB_SO ~ MIB_S18	19
PSU1_Voltage	20
PSU1_Current	20
PSU1_Fan_Status	20
PSU1_Temperature	20
PSU2_Voltage	20
PSU2_Current	20
PSU2_Fan_Status	20
PSU2_Temperature	20
ReaFan1_Status ~ RearFan5_Status	20
Temp_Rear_Left	20
Temp_Rear_Center	20
Temp_Rear_Right	20
<b>Events Menu</b>	<b>21</b>
Introduction	21
What is the Goal of an event?	21
Events	21
Announcements	21
PSU_T	21
PSU_B	21
Temperature	21
Ref_Backup	21
Fans	21
Card-Presence	21
What information is available in an event?	22
The Message String	22
The Tag	22
Defining Tags	22
The Priority	22
The Address	22
<b>Backup, Restore and About menus</b>	<b>23</b>
Introduction	23
Backup Menu Item	23
Restore Menu Item	23
About Menu Item	23
<b>Upgrading the ERC/ERS in Cortex</b>	<b>24</b>
Micro Firmware	24
Parameter Table	24
SPFS1 ~ SPFS18	24
<b>LED indication</b>	<b>25</b>
Front Panel LEDs	25
Error LED	25
Communication LEDs	25
<b>Networking explained</b>	<b>26</b>
Synapse In A Network	26
Network Terminology	26
IP Addressing	26
IP Address Representation	26
Network and Host Number Network Prefix	26
Subnet Mask	26
IP Gateway	26
ACP Considerations	27
<b>SNMP explained (ERS108-118 only)</b>	<b>28</b>
Introduction	28
Agent Setup & Usage	28
Loading MIB Files	28
Setting Up Traps	28
Where are the MIB files?	29
Agent Specifications	29
<b>Example configurations</b>	<b>30</b>
Quick Setup	30

Operation On A Network Using DHCP	31
Further Reading	32
<b>Connector Panel</b>	<b>33</b>
Ethernet failover	33
USB relay for remote PSU monitoring	33
<b>Specification</b>	<b>34</b>
Ethernet	34
Video Reference	34
Software	34
Miscellaneous	34
<b>GNU Public License version 2</b>	<b>35</b>

# 1 Introduction to Synapse

## An Introduction to Synapse

Synapse is a modular system designed for the broadcast industry. High density, intuitive operation and high quality processing are key features of this system. Synapse offers a full range of converters and processing modules. Please visit the AXON Digital Design Website at [www.axon.tv](http://www.axon.tv) to obtain the latest information on our new products and updates.

## Local Control Panel

The local control panel gives access to all adjustable parameters and provides status information for any of the cards in the Synapse frame, including the Synapse rack controller. The local control panel is also used to back-up and restore card settings.



**Note:** “Axon Cortex” software will increase system flexibility of one or more synapse frames

Although not required to use Cortex with a Synapse frame, you are strongly advised to use a remote personal computer or laptop PC with Axon Cortex installed, as this increases the ease of use and understanding of the modules.

## 2 Unpacking and Placement



**Note:** “The ERS/ERC108-118 is already installed in your SFR08 or SFR18 frame. The instructions below are only necessary for replacement of the rack controller.”

### Unpacking

The Axon Synapse card must be unpacked in an anti-static environment. Care must be taken NOT to touch components on the card – always handle the card carefully by the edges. The card must be stored and shipped in anti-static packaging. Ensuring that these precautions are followed will prevent premature failure from components mounted on the board.

### Placing the card

The rack controller card can be placed vertically in an SFR18 frame, on the right side next to the AC connectors. Locate the guide slots to be used, slide in the mounted circuit board, and push it firmly to locate the connectors. In an SFR08 the rack controller is placed horizontally

Correct insertion of the controller is essential.



### 3 A Quick Start

#### Powering-up


On powering up the Synapse frame, the card set will use basic data and default initialisation settings.

#### Changing settings and parameters

The front panel controls or the Axon Cortex can be used to change settings. An overview of the settings can be found in chapter 5, 6 and 7 of this manual.

#### Front Panel Control

Front Panel Display and Cursor




Settings are displayed and changed as follows;

Use the cursor 'arrows' on the front panel to select the menu and parameter to be displayed and/or changed.

- Press ► To go forward through the menu structure.
- Press ◀ To go back through the menu structure.
- Press ▲ To move up within a menu or increase the value of a parameter.
- Press ▼ To move down through a menu or decrease the value of a parameter.


NOTE: Whilst editing a setting, pressing ► twice will reset the value to its default.

Using the Synapse Local Control interface accessible from the front panel enables the Synapse system to be configured manually. On completion of the power up sequence the Local Control display shows:



Axon Synapse Control  
Press > Key

By pressing the right arrow key once, the Local Control proceeds to the slot configuration selection. Slots are numbered 0 to 18 for an SFR18 and 0 to 8 for an SFR08. Slot 0 is the ERC/ERS108-118 itself and slots 1..18 are the card positions within the frame (examples show ERS/ERC108-118).



ERS118 [Select Card]  
>S00=ERS118

Scrolling through these slots is performed using the up and down arrow key. Pressing the right-arrow key again enters the following menu where 6 predefined sub-menus can be selected. These are Status, Settings, Alarms, Backup, Restore and About.

```
ERS118 [Select Menu]
>Status
```

Press the right arrow key again to go to the status menu. Pressing the down arrow enters the menu that gives all status related menu items of a card. For the ERS/ERC108-118 the first status item is the 'NET STATUS' header. Pressing the down arrow again you get the IP\_Adrr0 status item (scrolling as it doesn't fit the display).

```
ERS118 [Status]
>IP_Addr0=DHCP Asking
```

As status items in this menu are not changeable, the right arrow key does not activate another menu level. Pressing the left arrow key once returns the menu to the previous item, thus the following menu is displayed again:

```
ERS118 [Select Menu]
>Status
```

If the down arrow key is pressed, the display will show:

```
ERS118 [Select Menu]
>Settings
```

Pressing the right arrow key enters the settings menu. After pressing the down arrow key the first setting and its value are now displayed.

```
ERS118 [Settings]
>IP_Conf0=DHCP
```

Other settings can be selected by pressing the up and down arrow keys. Pressing the right arrow key will edit the setting that is currently selected.

```
ERS118 [Edit Setting]
IP_Conf0>DHCP
```

Pressing the up and down keys changes the value of this setting. To change large range values, e.g. H-Phase, keeping the up or down arrow key pressed gives a faster increment or decrement of the value. The value can be reset by pressing the right key when the value is being edited. The display will show Press> to reset in order to confirm the reset.

```
Press > to reset
IP_Conf0>DHCP
```

Pressing the right arrow key again confirms the action and resets the setting. Pressing the left arrow key whilst in the card selection section of the ERS/ERC108-118 will present an 'Alarms' page where the last alarm can be viewed. If the Error LED is lit, the alarm responsible for the error will remain on the display and no further alarms will be displayed until the Error LED is cleared. To clear the Alarm and Error LED press the left arrow key whilst viewing the alarms page. To exit the Alarms page, use the right arrow key.

An example of the display under normal conditions when no alarms have occurred or when an alarm has cleared.

[No Alarms]

An example of the display when an Alarm has occurred.

S15 [Alarm Trigger]  
001:INP\_LOSS

#### Menu Structure Example

Slot	Module	Item	Parameter	Setting
▲				
▲				
S02		Identity		
▲				
S01	SFS10	▶ Set-tings	▶ Standard_d ig	▶ Auto
▼		▼	▼	▼
S00	ERS118	Status	Mode	625
		▼	▼	▼
		Events	Ref-Input	525
			▼	
			H-Delay	
			▼	
			▼	

#### Introduction to Cortex

To set up a frame's rack controller, we strongly advise to have Axon Cortex installed on a PC which is connected to the rack controller via Ethernet. Cortex is a windows based application to configure, manager and control your equipment. Cortex employs Ethernet communication to each device in your chosen workflow, providing the ability to both configure and monitor devices at local and remote sites.

The application allows up to 64 user-groups to be defined. For each group the level of access can be restricted, not only to program functionality but also to control access of individual settings on specific devices. Limitless users can be added and assigned to one of these groups, each with their own unique password.

**Download the latest version**

Cortex works with all Synapse products without upgrade or the purchase of additional software. Advanced features, such as integrated router control, user-configurable GUIs and third-party SNMP monitoring, are available as costed options, and are protected by the use of a USB dongle for the purchased options.

**Minimum system requirements**

A free-of-charge version of Cortex is available to customers from AXON's website ([www.axon.tv](http://www.axon.tv)). Make sure that you have the latest version when setting up a new frame.

The following list, lists the prerequisite software and minimum hardware and software requirements for running Cortex. To determine if the computer meets the system requirements, from the **Start** menu, right-click **My Computer**, and then click **Properties**. The **General** tab displays the CPU type and speed, and the amount of installed memory (RAM).

**Prerequisite software**

Microsoft .NET Framework (Automatically installed if not present)

Microsoft Internet Explorer 6.0 Service Pack 1 (SP1) or later (prerequisite for .NET Framework)

Adobe Reader V8 or later ([www.adobe.com/products/reader](http://www.adobe.com/products/reader)) for manual viewer

**RAM**

Minimum: 192 MB

Recommended: 512 MB or higher

**Hard Disk space**

Minimum: 600 MB (please note the SQL database size in Cortex should be reduced if HDD space is limited below 1GB)

Recommended: 1GB or higher

**Processor**

Pentium III Compatible or higher

Minimum: 500 MHz

Recommended: 1 GHz or higher

**Recommended Screen Resolution**

At least 1024 x 768

**Other**

Ethernet/Wireless adapter fitted with support for IP connections

**Operating System**

Windows Server 2003 SP1

Windows Server 2003 Enterprise Edition SP1

Windows Server 2003 Datacenter Edition SP1

Windows Server 2003 Web Edition SP1

Windows Small Business Server 2003 Standard Edition SP1

Windows Small Business Server 2003 Premium Edition SP1

Windows XP Professional SP2

Windows XP Home Edition SP2  
 Windows XP Tablet Edition SP2  
 Windows XP Media Edition SP2  
 Windows 2000 Professional Edition SP4  
 Windows 2000 Server Edition SP4  
 Windows 2000 Advanced Edition SP4  
 Windows 2000 Datacenter Server Edition SP4  
 Virtual PC  
 Virtual Server  
 Windows Vista Home Basic  
 Windows Vista Home Premium  
 Windows Vista Business  
 Windows Vista Enterprise  
 Windows Vista Ultimate  
 Windows 7

**Note:** There is no support in this release for Windows XP Embedded Edition.

**Installation of Cortex**

When you've downloaded the latest version, extract the file onto a local drive and click on the file named 'setup.exe'.

The Cortex installer will start by installing SQL Server 2005 Express SP2, this is a pre-requisite for running Cortex as all the local data storage is stored using this server. Accept the initial licence agreement for this and then wait whilst this application installs (likely to take between 5 and 20 minutes depending on the specification of the PC). The Cortex application will then be installed by following the on screen directions which will complete the rest of this installation.

**Logging on**

When starting the Cortex application for the first time it will automatically log the user on as an Administrator, however if the options have changed previously it can prompt the user for the User name and password. By default the User name is Admin, which can be selected from the pull down list and the password is "Cortex" (case sensitive). Once the application has finished its initialisation sequence the user can change the list of users and passwords for each user.

**Network adapter**

When the program is invoked it will by default carry out a search on the sub-net of the first network adapter installed in the PC. If it finds Synapse frames on this sub-net it will add and display them in the system view. If you require to use a different network adapter by default then this can be changed in the IP tab of the Configuration dialog. Also if other sub-nets contain Synapse frames then these can either be manually added using System->Add Frame to Network or by searching additional sub-nets again configured from the IP tab of the Configuration dialog.

When the program finds a rack controller it will then interrogate the frame and cards it contains to pull back all the information from them.

It will add status events to the log on reading the status so that the initial status level for the device will reflect its current state.

#### **Windows firewall**

When the program is run for the first time the Windows firewall will normally warn the user of a security risk. In order for Cortex to work correctly the unblock button should be pressed. If the firewall blocks the program then the broadcast network UDP messages will be blocked and Cortex will not update to reflect changes made by other clients on the Synapse system.

If the program has been blocked then it can be changed by accessing the Windows Firewall from the Control Panel. The exception dialog will allow the user to 'Add Program' by browsing to the executable and adding this to the list of exceptions.

Note that some network switch devices can also block network UDP broadcast messages so if these broadcasts are still not seen with Cortex in a Synapse system after checking the firewall then the configuration of 'intelligent' hubs or switches should also be verified.

## 4 The ERS/ERC108-118 Card

### Introduction

The ERC118 is the central controller of the Synapse SFR18 system frame. The ERC108 is the controller of the Synapse SFR08 system. The ERS108 and 118 include an SNMP agent. It is used to configure, control and monitor Synapse systems and to provide network connectivity. The ERS/ERC108-118 also provides an input for two independent references with loop through.

### Automatic IP Address Configuration

If the network has a Dynamic Host Configuration Protocol (DHCP) server available, the Synapse system can use this service to configure its IP address settings automatically. Using `Settings>IP_Conf0`, choose DHCP.



**Remark:** “In most cases, the IP address that is assigned using DHCP is dynamic; it must be re-obtained regularly and it can change over time. Please contact the network administrator in order to configure the DHCP assigned IP address to be fixed. See Manual IP address configuration. .”

### Manual IP Address Configuration

Verify the IP address configuration in `Status>IP_Addr`, which should now read `DHCP Leased` or `DHCP Infin`. In case a DHCP server is not present, manual configuration must be used instead. See below.

Consult your network administrator to obtain an IP address, network prefix or subnet mask and gateway address. Use the `Settings>NetwPrefix0` to set the network prefix. Alternatively, if a subnet mask is given, use `Settings mNM0` to set the subnet mask. Use the `Settings>mIP0` item to set the IP address.

Use the `Settings>mGW0` item to set the gateway address. If you do not have a gateway, or gateway address, use `0.0.0.0` instead. (Use reset to quickly obtain `0.0.0.0`).

Finally, using `Settings>IP_Addr0`, choose Manual.

### MAC address

All RRC/ERC and RRS/ERS cards have a unique MAC address. Sometimes you are required to know this address in case your company uses secured networks and firewalls. A rack controller's MAC address contains 6 pairs of digits build up out of 2 parts, looking as follows: `xx : xx : xx : yy : zz : zz`

X = 00 03 41 -> axon MAC address

Y & Z = unique allocated numbers

In ERS/ERC108-118 the MAC address can be found under `Status > MAC0`. Note that this setting is not available in the RRS/RRC18.

## 5 Settings Menu

### Introduction

The settings menu displays the current state of each setting within the ERS/ERC108-118 and enables the item to be changed or adjusted. Settings can be changed using the front panel of the Synapse frame (SFR18 or SFR08) or via Cortex.

### NETWORK

#### IP\_Conf0

Configuring Synapse for an Internet Protocol network can be performed manually or it can be set automatically using DHCP. If IP\_Conf0 is set to Manual, IP addressing is configured through the IP0, NM0 (or NetwPrefix0) and GW0 (Gateway) settings. If it is set to DHCP, Synapse uses the DHCP network service to configure itself automatically. The default setting of IP\_Conf0 is DHCP.

#### mIP0

mIP0 sets the manual IP address of the Synapse system. This address is only used if IP\_Conf0 is set to Manual and the address becomes effective as soon as you leave the edit mode or if the address is reset. If an IP address is set manually, the mNM0 must also be set manually.

#### mNM0

The manual subnet mask of the Synapse system, mNM0. This mask is only used if IP\_Conf0 is set to Manual and the mask becomes effective as soon as the edit mode is left or if the mask is reset. There are only 32 valid subnet masks. An alternative way of configuring the subnet mask is by use of the NetwPrefix0 setting.

#### mGW0

mGW0 sets the manual gateway address used by the Synapse system to communicate with remote network hosts. This address is only used if IP\_Conf0 is set to Manual and the address becomes effective as soon as edit mode is left or if the gateway address is reset.

#### mPri\_DNS

mPri\_DNS sets the manual primary Dynamic Name Server (DNS), used by the synapse system to connect with a dynamic name location (for instance an NTP server), instead of only an IP address. This setting is only used if IP\_Conf0 is set to manual and the address becomes effective as soon as edit mode is left or if the DNS address is reset.

#### mSec\_DNS

mSec\_DNS sets the manual secondary Dynamic Name Server (DNS), used by the synapse system to connect with a dynamic name location (for instance an NTP server), instead of only an IP address. This setting is only used if IP\_Conf0 is set to manual and the address becomes effective as soon as edit mode is left or if the DNS address is reset.



<b>Broadcasts</b>	The <code>Broadcasts</code> setting indicates whether changes to the Synapse system should be announced on the local network using the Axon Control Protocol (ACP). When <code>Broadcasts</code> is enabled, every change is broadcast on the local network allowing local clients to monitor the Synapse system in real time. The settings of <code>Broadcasts</code> are <code>On</code> or <code>Off</code> . The default setting of <code>Broadcasts</code> is <code>On</code> .
<b>Forwarding0</b>	If <code>Forwarding0</code> is enabled, changes to the Synapse system are sent to a single host (through IP unicasting). This host's IP address can be set using the <code>FW0</code> setting. The settings for <code>Forwarding0</code> are <code>On</code> or <code>Off</code> . The default setting is <code>Off</code> .
<b>FW0</b>	<code>FW0</code> sets the IP address of a single IP host, possibly on a remote network, which receives Synapse system changes through the Axon Control Protocol (ACP). Only used when <code>Forwarding0</code> is enabled.
<b>Forwarding1</b>	Besides <code>forwarding0</code> , you can also set a second IP to forward system changes to. This is done with the setting <code>Forwarding1</code> . When it is enabled, changes to the Synapse system are sent to a single host (through IP unicasting). This host's IP address can be set using the <code>FW1</code> setting. The settings for <code>Forwarding1</code> are <code>On</code> or <code>Off</code> . The default setting is <code>Off</code> .
<b>FW1</b>	<code>FW1</code> sets the IP address of a single IP host, possibly on a remote network, which receives Synapse system changes through the Axon Control Protocol (ACP). Only used when <code>Forwarding1</code> is enabled.
<b>NetwPrefix0</b>	<code>NetwPrefix0</code> sets the manual IP network prefix of the Synapse system. This address is only used if <code>IP_Conf0</code> is set to <code>Manual</code> . The address becomes effective as soon as the edit mode is left or if the address is reset. An alternative way of configuring the network prefix is by use of the <code>mNM0</code> setting. The default setting of <code>NetwPrefix0</code> is <code>24 Bit</code> .
<b>ErrorThreshold</b>	If an alarm occurs with a priority above this threshold, the front cover error LED will be enabled. The error LED can be cleared by pressing the ◀ arrow key in the alarms page.
<b>Redund_Pwr_Test</b>	<code>Redund_Pwr_Test</code> tests the on-board redundant reference circuitry. If a reference amplifier fails, it is possible to switch over to the backup amplifier using this setting. If the on-board primary power supply fails, the second circuit is activated automatically. The settings of <code>Redund_Pwr_Test</code> are <code>On</code> and <code>Off</code> , the default setting is <code>Off</code> .

<b>Trap-Dest_0</b> (ERS108-118 only)	If Trap-Dest_0 is set to on, SNMP traps are delivered to the SNMP trap receiver for which the IP address must be set with the TD_0 setting. The default setting is off.
<b>TD_0</b> (ERS108-118 only)	TD_0 sets the IP address for the first SNMP trap receiver the SNMP manager. This is a unicast address on the local or remote network
<b>Trap-Dest_1</b> (ERS108-118 only)	If Trap-Dest_1 is set to on, SNMP traps are delivered to the SNMP trap receiver for which the IP address must be in TD_1. The default setting is off.
<b>TD_1</b> (ERS108-118 only)	TD_1 sets the IP for the second SNMP trap receiver or the SNMP manager. This is a unicast address on the local or remote network
<b>NTPServer1</b>	Here you can assign the primary NTP server IP address or DNS name to which the ERC/ERS should synchronize its date and time.
<b>NTPServer2</b>	Here you can assign the secondary NTP IP address or DNS name to which the ERC/ERS should synchronize its date and time, in case the ERC/ERS cannot synch to the primary NTP server.
<b>NTPOffsetH</b>	With this setting you can add an offset in hours to the NTP time between -15 and +15 hours. Since NTP is usually UTC, this setting should be set conform your time zone.
<b>NTPOffsetM</b>	With this setting you can add an offset in minutes to the NTP time between -59 and +59 minutes.
<b>Time_Broadcast</b>	With this setting you can switch on or off in-frame broadcasting (via the internal bus) of the NTP time code to all cards.
<b>USB-Relay_chk</b>	<p>The ERC/ERS does not have a general pupose interface (GPI) like the RRC/RRS models had. However, the USB interface can be used to connect a USB relay for remote monitoring of your power supply status and general errors.</p> <p>To use this function, you have to buy a USB relay controller. The ERC/ERS has built in compatibility with this hardware :  <a href="http://kmtronic.com/usb-relay-controller-two-channels.html">http://kmtronic.com/usb-relay-controller-two-channels.html</a></p> <p>This little plastic box has one USB connector and two phoenix style screw terminals.</p>

At power up Relay 1 will be closed (active, so NO is close). If one of the two (or both) power supplies ceases to function, the relay is released. Relay 2 will be hard coupled to the error led on the front and is normally open.

This menu item is added in case only one power supply is used.

Possible settings are:

- Supply1: only PSU1 is monitored
- Supply2: only PSU2 is monitored
- Supply1-2: both power supplies are monitored (default)

If the ERC starts up and the USB dongle is present, relay1 will be set. The PSU monitoring thread will monitor the power supplies every second and set the PSU LEDs accordingly. Each time it will check if the relay is there and set the relay value accordingly (taking the value of `USB-relay_chk` into account).

Whenever the alarm LED is set, relay 2 is closed; whenever the alarm LED is reset relay 2 is closed.

**Note:** If the relay is plugged into a running ERC and the alarm LED is lit, the ERC will NOT close relay2. Closing relay2 will only happen if the relay is present at the time the alarm LED will be set. Of course after resetting the alarm relay2 will operate as expected.

**Note:** When a different serial device with an FT232 chipset is connected to the ERC the behaviour is undefined.

### **Fan\_Speed\_Control** (For SFR18-Gen3 only)

Allows to select fan speed setting

- Fast (100% pwm)
- Medium (80% pwm)
- Slow (60% pwm)

The preferred setting is `Fast` for optimal cooling.

**Warning:** when choosing a lower setting monitoring of temperatures is required.

## 6 Status Menu

<b>Introduction</b>	The status menu indicates the status of each item listed below.
<b>IP_Addr0</b>	Shows the current IP acquire method. Can be Manual, DHCP_Asking, DHCP_Leased or DHCP_Infin.
<b>IPO</b>	Shows the current IP address in use by the Synapse system
<b>NMO</b>	shows the current IP subnet mask in use by the Synapse system
<b>GW0</b>	Shows the current gateway IP in use by the Synapse system
<b>MAC0</b>	This item shows the ERC/ERS' MAC address.
<b>Pri_DNS</b>	Shows the current primary DNS server in use by the Synapse system.
<b>Sec_DNS</b>	Shows the current secondary DNS server in use by the Synapse system.
<b>PSU_Top</b>	PSU_Top gives the status of the top power supply within the Synapse frame. The status can be OK or NA (not available).
<b>PSU_Bottom</b>	PSU_Bottom gives the status of the Bottom power supply within the Synapse frame. The status can be OK or NA (not available).
<b>Temp_Left</b>	Temp_Left gives the current temperature (in degrees Celsius) of the left side inside the Synapse frame as measured by the temperature sensor. The status displays -999 when a fan is not connected, or the sensor is defect.
<b>Temp_Right</b>	Temp_Right gives the current temperature (in degrees Celsius) of the right side inside the Synapse frame as measured by the temperature sensor. The status displays -999 when a fan is not connected, or the sensor is defect.
<b>ERC_Temp</b>	ERC_Temp gives the current temperature (in degrees Celsius) of the ERS/ERC108-118 itself as measured by the onboard temperature sensor. Displays -999 if the sensor is defect.

<b>Temp_Front</b> (ERC/ERS108 only)	Temp_Front gives the current temperature (in degrees Celsius) of the front size inside the Synapse frame as measured by the temperature sensor on the Fan tray. Displays -999 if the sensor is defect.
<b>Left_Fan_Status</b>	Indicates the status of the left backside fan (inside the top lid of the SFR18). Can be NA (Not available), Error or OK.
<b>Right_Fan_Status</b>	Indicates the status of the right backside fan (inside the top lid of the frame). Can be NA (Not available), Error or OK.
<b>Front_Fan_Status</b> (ERC/ERS108 only)	Indicates the status of the front tray fan. Can be NA (Not available), Error or OK.
<b>Fans_PwrStatus</b> (ERC/ERS118 only)	Indicates the status of the power supply to the fans. Can be OK or Error.
<b>Front_PwrStatus</b>	Indicates the status of the power supply to the front of the frame. Can be OK or Error. This item is not available in the ERC/ERS108.
<b>SPF_Status</b>	SPF_Status give the current status of the Synapse Package File (SPF). The status can be Idle, Done, Busy or Error. When SPF_Status indicates Idle or Done the ERS is ready to receive a Synapse Package File. When SPF_Status indicates Done this shows that the last download was successful.
<b>SPF_Progress</b>	SPF_Progress indicates the progress of a programming action in progress. Initially it will be at 100%. While programming the value will start at 0% and increase to 100%, only to be reset to 0% when the next programming action starts.
<b>Redund_Ref_Pwr</b>	Redund_Ref_Pwr indicates whether the onboard reference power supply is available. The status can be OK or NA (not available).
<b>NTP_Status</b>	This status item indicates that status of the NTP sync. Can be NTP Not Synced, NTP Synced or Lost NTP Sync.
<b>MIB_SO ~ MIB_S18</b> (ERS108-118 only)	MIB_Slot number indicates the MIB file and version required for each slot. Note that replacing a card can change the required mib because a new firmware version may change existing objects and may introduce new objects and values.

<b>PSU statuses (only available in SFR18-Gen3 and SFR08 frames)</b>	
<b>PSU1_Voltage</b>	Voltage measurement of the bottom power supply. Nominal value is 30V.
<b>PSU1_Current</b>	Current measurement of the bottom power supply. Value depends on the cards inside the rack.
<b>PSU1_Fan_Status</b>	Status of the bottom power supply fan. Can be NA (Not Available), Error or OK.
<b>PSU1_Temperature</b>	Ambient temperature of the bottom power supply in degrees Celsius. Will be set to -999 when not available.
<b>PSU2_Voltage</b>	Voltage measurement of the top power supply. Nominal value is 30V.
<b>PSU2_Current</b>	Current measurement of the top power supply. Value depends on the cards inside the rack.
<b>PSU2_Fan_Status</b>	Status of the top power supply fan. Can be NA (Not Available), Error or OK.
<b>PSU2_Temperature</b>	Ambient temperature of the top power supply in degrees Celsius. Will be set to -999 when not available.
<b>Rear fan statuses (only available in SFR18-Gen3 frames)</b>	
<b>RearFan1_Status ~ RearFan5_Status</b>	Status of the rear fans in an SFR18-Gen3. RearFan1 is the left most fan, seen from the front. RearFan5 is the right most fan, seen from the front. Status can be NA (Not Available), Error or OK.
<b>Temp_Rear_Left</b>	Temperature at the left side of the rear fans, seen from the front, in degrees Celsius. Will indicate -999 when not available.
<b>Temp_Rear_Center</b>	Temperature at the center of the rear fans, seen from the front, in degrees Celsius. Will indicate -999 when not available.
<b>Temp_Rear_Right</b>	Temperature at the right side of the rear fans, seen from the front, in degrees Celsius. Will indicate -999 when not available.

## 7 Events Menu

<b>Introduction</b>	An event is a special message that is generated on the card asynchronously. This means that it is not the response to a request to the card, but a spontaneous message.
<b>What is the Goal of an event?</b>	The goal of events is to inform the environment about a changing condition on the card. A message may be broadcast to mark the change in status. The message is volatile and cannot be retrieved from the system after it has been broadcast. There are several means by which the message can be filtered.
<b>Events</b>	The events reported by the ERS/ERC108-118 are as follows;
<b>Announcements</b>	<code>Announcements</code> is not an event. This item is only used for switching the announcement of status changes on/off. 0=off, other =on. Beware: This does NOT influence the announcement from the cards within the frame or the announcing of the Frame Status object. Use the 'Settings' menu items 'Broadcasts' and 'Forwarding' for Announcement propagation on the network.
<b>PSU_T</b>	The removal or failure of the top PSU, can be detected and monitored using this event.
<b>PSU_B</b>	The removal or failure of the bottom PSU can be detected and monitored using this event.
<b>Temperature</b>	If the temperature inside the Synapse frame rises above 50 degrees Celsius and the priority of Temperature is set greater than zero an event is generated. 50°C is the upper limit of the operating temperature range.
<b>Ref_Backup</b>	The failure of the reference power circuitry can be detected and monitored using this event.
<b>Fans</b>	The failure of fans can be detected and monitored using this event.
<b>Card-Presence</b> (ERS108-118 only)	Insertion or removal of any card is signalled by this event.

### What information is available in an event?

The message consists of the following items;

- 1) A message string to show what has happened in text, for example: “INP\_LOSS”, “REF\_LOSS”, “INP\_RETURN”.
- 2) A tag that also shows what happens, but with a predefined number: e.g. 1 (= loss of input), 2 (= loss of reference), 129(= 1+128 = return of input). For a list of these predefined tags see the table on the next page.
- 3) A priority that marks the importance of an event. This value is defined by the user and can have any value between 1 and 255, or 0 when disabled.
- 4) A slot number of the source of this event.

### The Message String

The message string is defined in the card and is therefore fixed. It may be used in controlling software like Cortex to show the event.

### The Tag

The tag is also defined in the card. The tag has a fixed meaning. When controlling or monitoring software should make decisions based on events, it is easier to use the tag instead of interpreting a string. The first implementation is the tag controlled switch in the GPI16.

In cases where the event marks a change to fault status (e.g. 1 for Loss of Input) the complement is marked by the tag increased by 128 (80<sub>hex</sub>) (e.g. 129 (81<sub>hex</sub>) for Return of Input).

### Defining Tags

The tags defined for the ERS/ERC108-118 are:

Event Menu Item	Tag		Description
Announcements	0 or NA	0 or NA	Announcing of report and control values
PSU_T	07 <sub>hex</sub> =PSU_ERROR	87 <sub>hex</sub> = PSU_OK	Power Supply status
PSU_B	07 <sub>hex</sub> = PSU_ERROR	87 <sub>hex</sub> = PSU_OK	Power Supply status
Temperature	0A <sub>hex</sub> =TEMP_TOO_HIGH	8A <sub>hex</sub> = TEMP_OK	Temperature OK or higher than threshold
Ref_Backup	09 <sub>hex</sub> = REF_BACKUP_ERROR	89 <sub>hex</sub> = REF_BACKUP_OK	Reference status
Fans	33 <sub>hex</sub> = FAN_SPEED_LOW	87 <sub>hex</sub> = FAN_SPEED_OK	Fan status
Card presence	14 <sub>hex</sub> = Card inserted	09 <sub>hex</sub> = Card removed	Monitors card presence

### The Priority

The priority is a user-defined value. The higher the priority of the alarm, the higher this value. Setting the priority to Zero disables the announcement of this alarm. Alarms with priorities equal or higher than the ErrorThreshold setting of the ERC/ERS will cause the error LED on the Synapse rack front panel to light.

### The Address

Together with the message string or the tag, the slot number or address of the card is relevant to be able to assign the event to a certain card.



## 8 Backup, Restore and About menus

### Introduction

The Backup, Restore and About menus provide file management facilities and identification information for the cards installed in the Synapse frame. Backup, Restore and About can be accessed from the front panel of the Synapse frame only.



**Note:** Backup and restore does not work for all cards. Linux cards do not support this feature.

### Backup Menu Item

There are no settings to backup for the ERS/ERC108-118, the settings are automatically stored in non-volatile memory.

On the ERS/ERC108-118 there is backup memory space for the card inserted in slots 1 to 18. This space is used to manually store the actual settings of a card, automatic backups are not performed. Backups can only be restored to the same slot and to a card of identical type and micro firmware version.

The Parameter Table file on each card is used as the source for these backups. The ACP protocol also provides access to these files for fast configuration of a card. These files are unstructured and have only a valid meaning for the actual software on the card.

### Restore Menu Item

The ERC/ERS can backup the settings from cards in slot 1 to 18 but not its own settings. Restoring can be manually performed for slots 1 to 18 to configure a card when it is replaced or hot swapped.

### About Menu Item

These items describe the identity of the card. In order of appearance:

- Card Label
- User Defined Label
- Card Description
- Software Version
- Hardware Version
- Product Code
- Serial Number
- Card ID
- Key
- Features
- SNMP

The user defined label can be used to label the Synapse system. It can be set by the remote configuration software.

## 9 Upgrading the ERC/ERS in Cortex

### Micro Firmware

The micro firmware file is zero sized and only provides a dialog to enable the so called "boot mode". In this mode the ERC/ERS firmware can be upgraded.

To upgrade the ERC/ERS perform the following steps:

1. Make sure the ERC/ERS is connected to an Ethernet network and can be reached using the Cortex application.
2. If the ERC/ERS IP addressing is not currently configured, contact a network administrator to obtain IP address settings for the network.
3. Ensure that your network functions correctly, if the network performs poorly the update MAY fail. E.g. if the network suffers from broadcasts storms a bounded amount of required retries may not suffice.
4. In Cortex locate your frame; expand it using the + icon in front of it. Right click on the line for the ERS/ERC108-118 and select "Upload Firmware" from the popup menu
5. At the bottom of the modal dialog that now shows up select the SPF file you want to upgrade to.
6. Select the checkbox on the top left to the card named "Rack controller" In the file column the name of the spf file will now show. Make sure that you have no other boxes checked.
7. Press the button "Program Devices". A confirmation dialog will show up informing you that this will interrupt the operation of the device. Confirm this message if you want to proceed. After this there can be a second confirmation. This only happens if there is another programming action in progress or if the previous programming action failed. Warning: Confirming this second message will result in aborting the already ongoing programming action!
8. The upload can take up to a minute or more if your network is busy. Once completed the ERC/ERS will automatically return to operational mode. Where possible existing settings will be retained.

### Parameter Table

This is not used. It's only here for compatibility purposes.

### SPFS1 ~ SPFS18

Synapse Package files (SPF) for each slot within the frame. Use these files to update the firmware on a card. The ERC/ERS will perform checks on the file to prevent corruption of firmware and performs automatic bootmode / operational mode settings.

## 10 LED indication

### Front Panel LEDs

The PSU1/PSU2 LEDs in the Synapse frame cover show the availability and functioning of the PSUs. The error LED shows a triggered alarm from within the frame with a priority above the Error Threshold setting.

### Error LED

The error LED remains lit until explicitly cleared by user intervention. Cleared alarms will not disable the error led. The error LED can be cleared by pressing the ◀ key in the alarms page.

### Communication LEDs

The two LEDs of each network interface of the ERS/ERC108-118 itself display a valid link and activity on the network. If the Ethernet is connected properly the left link-led should be lit. The right activity LED blinks when there is network activity.

## 11 Networking explained

### Synapse In A Network

The Synapse frame can be connected to a network using its Ethernet STP connector. Synapse uses the Internet Protocol (IP) to communicate with other devices on the network; often computers. The network may be as small as a link between a PC and the Synapse system or as large as the entire Internet.

### Network Terminology

By connecting the Synapse system to an IP network, it becomes a so-called host. As a host, the Synapse system can be reached from other hosts such as computers. The network may be a part of any number of interconnected networks, such as the Internet. Multiple networks are interconnected by routers and gateways. The network the Synapse system is directly connected to, is called the subnet, or local network. Other connected networks are called remote networks. A host usually has one interface on the network, routers and gateways have multiple network interfaces

### IP Addressing

Each host interface connected to an IP network has a unique IP address, so an attached Synapse system has its own address as well.

### IP Address Representation

IP addresses are represented as four decimal numbers, separated by periods. Each number ranges from 0 to 255 (inclusive), representing one byte (or eight bits). So, in total, an IP address consists of four times eight bits, which equals 32 bits. For example, 10.17.209.8 and 127.0.0.1 both are valid IP addresses. It is suggested that leading zeros are omitted, as some operating systems will use this to indicate octal notation. Therefore, instead of using 010.017.209.008, use 10.17.209.8.

### Network and Host Number Network Prefix

The first series of bits represent the local network number, the remaining number of bits represent the unique host interface number of the host on that local network. The number of bits that define the network number is called the Network Prefix and ranges from 0 to 32 bits (inclusive). For the ERS/ERC108-118 the maximum is 30 bits. Prefixes of 31 and 32 do not yield a usable network.

### Subnet Mask

An alternative way to represent the network prefix is to write the four decimal numbers that correspond to all network number bits set to 1, and all host number bits set to 0. This notation is called the subnet mask. For example, a network prefix 255.255.0.0 corresponds with a network prefix of 16 bits.

### IP Gateway

If the local network is connected with other networks, the Synapse system needs the IP address of a gateway to the other networks. However, gateways do not propagate the Synapse system Announcements so they do not reach computers outside the local network.

## ACP Considerations

Management protocols like ACP and SNMP use the unreliable transport protocol UDP. This is a simple wrapper protocol for sending data using IP packets directly instead of using a reliable TCP connection. TCP is also possible for up to 10 clients.

The result of this is a fast transfer of events or notifications to the management station. Because there is no connection between the hosts the use of the broadcast address is allowed. ACP Announcements are sent using this subnet broadcast address.

In the broadcast address the host part of the IP address is all set to binary ones. You can easily calculate this broadcast address by OR-ing your inverted subnet mask with the IP address.

Example:

The Subnet Mask is 255.255.255.0

The host IP Address is 192.168.0.1

Thus 255.255.255.0 inverted is 0.0.0.255. OR-ed with 192.168.0.1 gives us 192.168.0.255 as broadcast address. As stated earlier, Announcements do not pass the gateway. The Forward Address setting of the system can be used to send the Announcements to one host inside or outside the local network.

This host can be used to further propagate the Announcements and is thus an Application Gateway for the ACP protocol.

## 12 **SNMP explained (ERS108-118 only)**

### **Introduction**

The Simple Network Management Protocol (SNMP) is part of the TCP/IP suite of protocols. It can be used for controlling and monitoring network equipment and other devices, the Axon SFR18, SFR08 and SFR04 for example. Such devices are called 'Agents' in SNMP terminology. Since SNMP is a standard TCP/IP protocol, management applications are available from third parties such as HP additional solutions are available from the public domain. The section 'Further Reading' gives a starting point to find more information about this subject.

The SNMP is 'simple' since there are only 4 'functions' in SNMPv1. This is also true because the 'Structure of Management Information' restricts the managed data types to approximately 10. Though the protocol is 'Simple' it is not 'Trivial'. Building your own SNMP application or setting up Management station can take some time

### **Agent Setup & Usage**

Here are a few guidelines for installing the Agent, without explaining the specific details of your management application

### **Loading MIB Files**

Before the Agent can be used it is advisable to load the card MIB files into your Management application. A description on how to load the MIBs should be included in the documentation of your SNMP Manager. There should not be any error or warning messages when loading the MIB. However if you do encounter an error, please report this with a short description of the error message to Axon Technical Support. The Agent does not need to load the card MIB files because it gets its management information directly from the cards. The SNMP agent is operational after powering up the rack controller

### **Setting Up Traps**

Synapse traps can be enabled by setting the 'Event' objects in a card MIB to a value greater than zero. The SNMP authentication failure trap can be enabled or disabled from the SNMP group in the MIB-2 tree.

The trap destination is set in the rack controller MIB by setting the "Trap-Dest\_0" object to 'on' and set the destination IP address in the 'TD\_0' object. The destination IP address is typically the address of your SNMP Management station or an SNMP proxy Agent.

If the rack controller is located outside your sub-network you must specify the gateway address mGW0 on your rack controller. These settings can also be performed from the local front panel of your frame.



## Where are the MIB files?

The MIB files are supplied on the CD-ROM provided with the Synapse frame or rack controller. If you cannot find the MIB file for the card in use, Axon may be able to generate such a file for you. The file may not be available as the card software version may not be fully SNMP compliant or for some other reasons. Please contact Axon Technical Support for details.

## Agent Specifications

The agent conforms to SNMPv1 (RFC1157), and MIB-II (RFC1213).

The following MIB-II groups are implemented:

system	.iso.org.dod.internet.mgmt.mib-2.system
interfaces	.iso.org.dod.internet.mgmt.mib-2.if
AT	.iso.org.dod.internet.mgmt.mib-2.at
ip	.iso.org.dod.internet.mgmt.mib-2.ip
icmp	.iso.org.dod.internet.mgmt.mib-2.icmp
udp	.iso.org.dod.internet.mgmt.mib-2.udp
snmp	iso.org.dod.internet.mgmt.mib-2.snmp

Below the enterprise number 7829 for Axon Digital Design there is room for Axon specific private MIBs.

Currently two nodes are defined.

.iso.org.dod.internet.private.enterprises.axon.synapse
.iso.org.dod.internet.private.enterprises.axon.synapsetraps

The synapse object identifier points to the cards that can be available in a Synapse frame. The installed cards are dynamically registered with the SNMP Agent.

The agent is capable of sending authentication failure traps. Alarms originating from the cards can be sent as SNMP generic traps. These traps are globally defined in the synapsetraps.mib file.

There is one fixed community. This is the standard 'public' community for both MIB-II and the Synapse MIBs.

# 13

## Quick Setup

## Example configurations

This is a reduced configuration for quick Setup.

For connection with a Microsoft windows PC or laptop without a DHCP server using a single hub or cross-cable.

In Windows NT based systems you need administrative rights on your machine to do this. If you're not familiar with these procedures, ask your local expert or network administrator to do this for you.

In Windows enter Start > Settings > Control Panel > Network > Protocols > TCP/IP (Properties) > IP Address

Specify an IP address: 192.168.0.1

Specify a Subnet Mask: 255.255.255.0

Specify a Default Gateway: 0.0.0.0

The last digit of the IP address is free to choose between 1 and 254, if not used already in your network. E.g. if you assign 192.168.0.1 to your PC, your frame(s) must be on 192.168.0.2, 192.168.0.3 etc.

The last zero in the Subnet Mask delimits this usable host range. There are thus 254 valid IP addresses on network 192.168.0.0 .

Restart your PC or laptop to activate these settings. The settings for the SFR18 must be: ERS/ERC108-118 > settings

	default	user setting
mIP0	= 0.0.0.0	= 192.168.0.2
mNM0	= 0.0.0.0	= 255.255.255.0
mGW0	= 0.0.0.0	= 0.0.0.0
Broadcasts	= Off/On	= On
Forwarding0	= Off/On	= Off
FW0	= 0.0.0.0	= 0.0.0.0
Forwarding1	= Off/On	= Off
FW1	= 0.0.0.0	= 0.0.0.0
NetwPrefix0	= 24 bits	= 24 bits
IP_Conf0	= DHCP/Manual	= Manual

When Broadcasts or Forwarding are set to On, Cortex can detect a frame power up. The correct setting of the Subnet Mask is vital to the operation of the network!

The broadcast IP address on this simple network is 192.168.0.255. The calculation of this address is explained in the chapter 11 'Networking Explained' under ACP Considerations.





## Operation On A Network Using DHCP

For connection with a Microsoft windows PC or laptop with a DHCP server. Ensure that the network you are going to use is not heavily loaded. See 'Networking Explained' under ACP Considerations.

In Windows enter Start > Settings > Control Panel > Network > Protocols > TCP/IP (Properties) > IP Address > Obtain an IP address from a DHCP server.

Ensure your computer runs the DHCP client and has an assigned IP address. You can view the current IP address of your computer by running the 'ipconfig' command from a DOS prompt.

Restart your PC or laptop to activate these settings.

The settings for the SFR must be: ERS/ERC108-118 > settings

	default	user setting
mIP0	= 0.0.0.0	= not relevant
mNM0	= 0.0.0.0	= not relevant
mGW0	= 0.0.0.0	= not relevant
Broadcasts	= Off/On	= On
Forwarding0	= Off/On	= Off
FW0	= 0.0.0.0	= 0.0.0.0
Forwarding1	= Off/On	= Off
FW1	= 0.0.0.0	= 0.0.0.0
NetwPrefix0	= 24 bits	= not relevant
IP_Conf0	= DHCP/Manual	= DHCP

The currently assigned IP0, NM0 and GW0 address can be viewed in the status menu.

When Broadcasts or Forwarding are set to On the Synapse configuration tool can detect a frame powering up.

As described in the chapter 4 "The ERS/ERC108-118 Card" the assigned addresses may change over time. Ask your network administrator for a fixed IP Address.

Note that a change of the network address or loss of connection of the ERC/ERS does not affect the operation of the frame

**Further Reading**

This manual describes the ERS/ERC108-118 card. For more information on the TCP/IP protocol suite:

Information about Ethernet can be found at: <http://www.ieee802.org>

ACP Source Development Kit (SDK) is available from Axon.

Documentation for the ACP protocol is available from Axon.

Internetworking with TCP/IP Principles, protocols, and architecture

Douglas E. Comer  
Prentice Hall

TCP/IP Illustrated  
W. Richard Stevens  
Addison-Wesley


RFCs can be obtained from <http://www.rfc-editor.org/>

Information about Ethernet can be found at

[http://docwiki.cisco.com/wiki/Internetworking\\_Technology\\_Handbook](http://docwiki.cisco.com/wiki/Internetworking_Technology_Handbook)

## 14 Connector Panel

The ERS/ERC108-118 backplane:



**!Unused inputs and outputs must be terminated with the correct impedance!**

### Ethernet failover

The ERS/ERC108-118 has 2 Ethernet connectors. These connectors logically define one network interface. They are configured as an auto failover. Since they constitute the same network interface, if a second cable is connected, it must be connected to the same network segment as the primary cable. If for whatever reason the input link of the primary ERC connector is lost, a failover will happen and the second network connector will get the same MAC and IP addresses. On the ERC/ERS118 the upper interface is the primary interface. On the ERC/ERS108 the right Ethernet interface is the primary one.

### USB relay for remote PSU monitoring

The ERC/ERS does not have a general purpose interface (GPI) like the RRC/RRS models had. However, the USB interface can be used to connect a USB relay for remote monitoring of your power supply status and general errors.

To use this function, you have to buy a USB relay controller. The ERC/ERS has built in compatibility with this hardware :

<http://kmtronic.com/usb-relay-controller-two-channels.html>

## 15 Specification

<b>Ethernet</b>	Interface	Shielded Twisted Pair (STP)
	Data rate	1Gb/s
<b>Video Reference</b>	Bandwidth	10MHz
	Input impedance	High (requires loop load)
	Input level	1Vpp@75Ohm
<b>Software</b>	Internet Protocol version 4 (IPv4) Classless Inter-domain Routing (CLID)	
	Internet Control and Management Protocol (ICMP) RFC792	
	User Datagram Protocol (UDP) RFC768	
	Dynamic Host Configuration Protocol (DHCP) per RFC 2131	
	Axon Control Protocol version 1 (ACP)	
	Documentation available from Axon	
<b>Miscellaneous</b>	Supply Voltage	30VDC
	Power Consumption	3.6W to 9W
	Weight	200g
	Operating temperature	0 °C to 50 °C
	Dimensions	144 x 153x 20 mm



## This product contains open-source software

This product contains open-source software licensed under the GNU Public License (GPL). A copy of the GNU Public License is included below. Under this license you are eligible to receive a copy of the source code of this software including any changes.

Axon Digital Design shall provide the source code on request either through physical distribution or electronic communication. For physical distribution you may be charged a fee that covers distribution costs. This offer is valid up to three years after date of purchase. Please direct your request to the support department of Axon Digital Design.

Axon Digital Design supports open-source software by participating in the development of open-source projects or submitting improvements to these projects. For more information see <http://opensource.axon.tv/>

## GNU Public License version 2

### TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,



- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.



#### **NO WARRANTY**

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.