

INSTALLATION & CONFIGURATION MANUAL

U4D100

4K ULTRA HD 4 WIRE TO 1080P DOWN
CONVERTER



SYNAPSE 





Copyright

EVS Broadcast Equipment S.A. – Copyright © 2001 – 2021. All rights reserved.

Disclaimer

The information in this manual is furnished for informational use only and subject to change without notice. While every effort has been made to ensure that the information contained in this user manual is accurate, up-to-date and reliable, EVS Broadcast Equipment cannot be held responsible for inaccuracies or errors that may appear in this publication.

Improvement Requests

Your comments will help us improve the quality of the user documentation. Do not hesitate to send improvement requests, or report any error or inaccuracy on this user manual by e-mail to doc@evs.com.

Regional Contacts

The address and phone number of the EVS headquarters are usually mentioned in the **Help > About** menu in the user interface.

You will find the full list of addresses and phone numbers of local offices either at the end of this user manual (for manuals on hardware products) or on the EVS website on the following page: <http://www.evs.com/contacts>.

User Manuals on EVS Website

The latest version of Media Infrastructure manuals are available at: <https://mi-sftp.evs.com/>
The user manuals for other EVS products can be found at the EVS download center, on the following webpage: <https://www.evs.com/en/download-area>.



WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE

- ALWAYS disconnect your entire system from the AC mains before cleaning any component. The product frame (SFR18 or SFR04) must be terminated with three-conductor AC mains power cord that includes an earth ground connection. To prevent shock hazard, all three connections must always be used.
- NEVER use flammable or combustible chemicals for cleaning components.
- NEVER operate this product if any cover is removed.
- NEVER wet the inside of this product with any liquid.
- NEVER pour or spill liquids directly onto this unit.
- NEVER block airflow through ventilation slots.
- NEVER bypass any fuse.
- NEVER replace any fuse with a value or type other than those specified.
- NEVER attempt to repair this product. If a problem occurs, contact your local EVS distributor.
- NEVER expose this product to extremely high or low temperatures.
- NEVER operate this product in an explosive atmosphere.

Warranty: EVS warrants their products according to the warranty policy as described in the general terms. That means that EVS Broadcast Equipment SA can only warrant the products as long as the serial numbers are not removed.

Copyright © 2001 – 2021 EVS Broadcast Equipment SA

Date created: 24-06-2014

Date last revised: 24-06-2014

EVS, the EVS logo and Synapse are trademarks of EVS Broadcast Equipment SA

This product complies with the requirements of the product family standards for audio, video, audio-visual entertainment lighting control apparatus for professional use as mentioned below.



| | |
|-----------------|----------|
| EN60950 | Safety |
| EN55103-1: 1996 | Emission |
| EN55103-2: 1996 | Immunity |

EVS Broadcast Equipment
U4D100



Tested To Comply
With FCC Standards

FOR HOME OR OFFICE USE

This device complies with part 15 of the FCC Rules
Operation is subject to the following two conditions:
(1) This device may cause harmful interference, and
(2) This device must accept any interference received, including
interference that may cause undesired operation.



Table of Contents

| | |
|--|-----------|
| Introduction to Synapse | 4 |
| An Introduction to Synapse | 4 |
| Local Control Panel | 4 |
| Remote Control Capabilities | 4 |
| Unpacking and Placement | 5 |
| Unpacking | 5 |
| Placing the card | 5 |
| A Quick Start | 6 |
| When Powering-up | 6 |
| Changing settings and parameters | 6 |
| Front Panel Control | 6 |
| Example of changing parameters using front panel control | 7 |
| EVS Cortex Software | 8 |
| Menu Structure Example | 8 |
| The U4D100 Card | 9 |
| Introduction | 9 |
| Features | 9 |
| Applications | 9 |
| Block schematic | 10 |
| Settings Menu | 11 |
| Introduction | 11 |
| IO_Prst_Act | 11 |
| IO_Prst_Edit | 11 |
| #Out-Frmt | 11 |
| #Out_Map | 11 |
| #Mode | 11 |
| #H-Sharpness | 12 |
| #H_delay | 12 |
| #V_delay | 12 |
| #F_delay | 12 |
| #OSD-Style | 12 |
| Lock-Mode | 12 |
| Ref-Type | 12 |
| Delay-Status | 13 |
| IP_Conf0 | 13 |
| mIP0 | 13 |
| mNM0 | 13 |
| mGW0 | 13 |
| NetwPrefix0 | 13 |
| Status Menu | 14 |
| Introduction | 14 |
| sInp1 | 14 |
| IO-Delay | 14 |
| Ref | 14 |
| IP_Addr0 | 14 |
| Mac0 | 14 |
| IP0 | 14 |
| NM0 | 14 |
| GW0 | 14 |
| Events Menu | 15 |
| Introduction | 15 |
| What is the Goal of an event? | 15 |
| Events | 15 |
| Announcements | 15 |
| Ref-Status | 15 |
| What information is available in an event? | 15 |
| The Message String | 15 |
| The Tag | 15 |
| Defining Tags | 16 |
| The Priority | 16 |

| | |
|-------------------------|-----------|
| The Address | 16 |
| LED Indication | 17 |
| Error LED | 17 |
| Input_1 LED | 17 |
| Reference LED | 17 |
| Connection LED | 17 |
| Error LED | 17 |
| Block Schematic | 18 |
| Connector Panels | 19 |

1 Introduction to Synapse

An Introduction to Synapse

Synapse is a modular system designed for the broadcast industry. High density, intuitive operation and high quality processing are key features of this system. Synapse offers a full range of converters and processing modules. Please visit the EVS Broadcast Equipment SA Website at <http://www.evs.com> to obtain the latest information on our new products and updates.

Local Control Panel

The local control panel gives access to all adjustable parameters and provides status information for any of the cards in the Synapse frame, including the Synapse rack controller. The local control panel is also used to back-up and restore card settings. Please refer to the RRC18, RRC10, RRC04, RRS18 and RRS04 manuals for a detailed description of the local control panel, the way to set-up remote control over IP and for frame related settings and status information.

Remote Control Capabilities

The remote control options are explained in the rack controller manual. The method of connection to a computer using Ethernet is also described in the ERC/ERS/RRC/RRS manual.



CHECK-OUT: “EVS CORTEX” SOFTWARE WILL INCREASE SYSTEM FLEXIBILITY OF ONE OR MORE SYNAPSE FRAMES

Although not required to use Cortex with a Synapse frame, you are strongly advised to use a remote personal computer or laptop PC with EVS Cortex installed, as this increases the ease of use and understanding of the modules.

2 Unpacking and Placement

Unpacking

The EVS Synapse card must be unpacked in an anti-static environment. Care must be taken NOT to touch components on the card – always handle the card carefully by the edges. The card must be stored and shipped in anti-static packaging. Ensuring that these precautions are followed will prevent premature failure from components mounted on the board.

Placing the card

The Synapse card can be placed vertically in an SFR18 frame or horizontally in an SFR04 and SFR08 frame. Locate the two guide slots to be used, slide in the mounted circuit board, and push it firmly to locate the connectors.

Correct insertion of card is essential as a card that is not located properly may show valid indicators, but does not function correctly.

NOTE: On power up all LED's will light for a few seconds, this is the time it takes to initialise the card.

3 A Quick Start

When Powering-up


On powering up the Synapse frame, the card set will use basic data and default initialisation settings. All LED's will light during this process. After initialisation, several LED's will remain lit – the exact number and configuration is dependent upon the number of inputs connected and the status of the inputs.

Changing settings and parameters

The front panel controls or the EVS Cortex can be used to change settings. An overview of the settings can be found in chapter 5, 6 and 7 of this manual.

Front Panel Control

Front Panel Display and Cursor



Settings are displayed and changed as follows;

Use the cursor 'arrows' on the front panel to select the menu and parameter to be displayed and/or changed.


- Press ► To go forward through the menu structure.
- Press ◀ To go back through the menu structure.
- Press ▲ To move up within a menu or increase the value of a parameter.
- Press ▼ To move down through a menu or decrease the value of a parameter.

NOTE: Whilst editing a setting, pressing ► twice will reset the value to its default.

Example of changing parameters using front panel control

With the display as shown below


RRC18 [Select Card]
>S01=SFS10



Pressing the ► selects the SFS10 in frame slot 01.

The display changes to indicate that the SFS10 has been selected. In this example the Settings menu item is indicated.

SFS10 [Select Menu]
>Settings



Pressing the ► selects the menu item shown, in this example Settings.

(Pressing ▲ or ▼ will change to a different menu eg Status, Events).

The display changes to indicate that the SFS10 Settings menu item SDI-Format has been selected and shows that its current setting is Auto.

SFS10 [Settings]
>SDI-Format=Auto



Pressing the ► selects the settings item shown, in this example SDI-Format.

(Pressing ▲ or ▼ will change to a different setting, eg Mode, H-Delay).

The display changes to indicate that the SFS10 Edit Setting menu item SDI-Format has been selected.

SFS10 Edit Setting
SDI-Format>Auto



To edit the setting of the menu item press ▲ or ▼.

All menu items can be monitored and/or changed in this way. Changing a setting has an immediate effect.



EVS Cortex Software

EVS Cortex can be used to change the settings of Synapse modules from a PC, either locally or remotely. The software enables communication based on TCP/IP between the Setup PC and Synapse frames/modules.

Each Synapse frame is addressed through its rack controller's unique IP address, giving access to each module, its menus and adjustment items. EVS Cortex has access to data contained within the Synapse module and displays it on a GUI. The software has an intuitive structure following that of the module that it is controlling.

For operation of EVS Cortex, please refer to the Cortex help files.

Menu Structure Example

| Slot | Module | Item | Parameter | Setting |
|------|--------|-------------|----------------|---------|
| ▲ | | | | |
| ▲ | | | | |
| S02 | | Identity | | |
| ▲ | | ▲ | | |
| S01 | SFS10 | ▶ Set-tings | ▶ Standard_dig | ▶ Auto |
| ▼ | | ▼ | ▼ | ▼ |
| S00 | RRC18 | Status | Mode | 625 |
| | | ▼ | ▼ | ▼ |
| | | Events | Ref-Input | 525 |
| | | | ▼ | |
| | | | H-Delay | |
| | | | ▼ | |
| | | | ▼ | |

NOTE: Further information about Front Panel Control and Synapse Cortex can be obtained from the RRC and RRS operational manuals and the Cortex help files.

4 The U4D100 Card

Introduction

The U4D100 is a 4K (3840x2180), 4 wire, to 1080p down-converter. The low latency unit combines and filters the four quadrants into a 1080p (1920x1080) signal.


Features

- Four wire 1080p 50 or 59.94 input (level B compliant)
- One 1080p signal on 4 outputs
- Low Latency (1 1080p Frame 20ms @ 50Hz, 16.7ms @ 59.94 Hz)
- 4K 4 wire (3840 x 2160)
- Compatible with the following formats (auto selecting)
 - 1080p/59.94
 - 1080p/50
- Transparent for 16 channels of embedded audio
- The BPH17 can optionally be fitted with up to two fiber I/O modules (inputs or outputs)
- Full control and status monitoring through the front panel of the SFR04/SFR08/SFR18 frame and the Ethernet port (ACP)

Applications

- Down conversion for 4K production sets

Block schematic



5 Settings Menu

Introduction

The settings menu displays the current state of each setting and allows you to change or adjust it. Settings can be changed using the front panel of the Synapse frame (SFR18, SFR08 or SFR04) or with Cortex. Please refer to chapter 3 for information on the Synapse front panel control and Cortex.

Note: All items preceded with a #-sign are part of the presets.

SYSTEM SETTINGS

IO_Prst_Act

With this item you can manually change the currently active IO settings. Can be any preset between 1 and 8. By default it is set to 1. Menu settings that are preceded with a '#'-prefix are part of the preset, *except for* the anaglyph mode presets.

IO_Prst_Edit

Here you can select which of the 8 selectable IO settings presets you want to edit. Changing this will not change the active preset, unless the currently active preset is the same you are going to edit. Menu settings that are preceded with a '#'-prefix are part of the preset, *except for* the anaglyph mode presets.

#Out-Frmt

With Out-Frmt you can set what the output format is. Possible settings are:

- 1080p60
- 1080p50
- Auto

#Out_Map

The setting item Out_Map determines if the output signal is mapped according Level-A or Level-B. on input A will be reclocked by the GDR216. The settings are:

- Auto: Output mapping follows input map detection.
- Level-A: Fixed level-A
- Level-B: Fixed level-B

The default setting is Auto.

#Mode

The setting Mode determines if the output signal is down converted or the input is passed to the output. Settings are

- Pass (Default)
- Down



| | |
|---------------------|---|
| #H-Sharpness | With H-Sharpness you can select how much detail enhancement you want to add. Ranges from 0% to 100%. The Default is 0%. |
| #H_delay | <p>The H-Delay setting allows adjustment of the Horizontal phase of the output signal with respect to the selected reference input.</p> <p>The H-Delay setting gives a delay in addition to the reference timing. For example: if the H-Delay is set to 10 pixels, the output signal will be delayed by reference timing + 10 pixels. The signal is delayed (advanced) with respect to the phase of the reference signal. The available range is from 0 to a maximum of 2639 pixels (depends on I/O format). The default setting is 0px .</p> |
| #V_delay | <p>V-Delay setting allows adjustment of the vertical phase of the output signal with respect to the selected reference input.</p> <p>The V-Delay setting gives a delay in addition to the reference timing. For example: if the V-Delay is set to 10 TV HD lines, the output signal will be delayed by reference timing + 10 TV HD lines. The signal is delayed (advanced) with respect to the phase of the reference signal. The available range is from 0 to a maximum of 1124 lines. The default setting is 0ln.</p> |
| #F_delay | F-Delay sets the amount of delayed Frames. The available range is from 0 to 7 frames. Default is 0F. |
| #OSD-Style | <p>Selects the style of the On Screen Display text. The following are possible:</p> <ul style="list-style-type: none">■ Off.■ Transp: Enables the text in transparent mode.■ Masked: Enables the text in masked mode.■ Blink-Transp: Blinks the text in transparent mode.■ Blink-Masked: Blinks the text in masked mode. |
| Lock-Mode | Lock-Mode determines whether the card is locked to his input (input 1), to the reference (Ref1 or Ref2) or freerun (not locked). By default it is set to Ref1. |
| Ref-Type | Sets the type of incoming reference. Can be either Bi-Level or Tri-Level. Default is Bi-Level. |

Delay-Status It is possible to display the processing time of the card in the status menu. This setting allows you to switch this function ON or OFF.
 Due to bus traffic the default setting is OFF.

NETWORK

IP_Conf0 With this setting you can let the card obtain an IP address automatically via DHCP, or appoint a manual set IP address. By default this setting is set to Manual.

mIPO When IP_Conf0 is set to manual, you can type in the preferred IP address here. By default it is set to 172.16.1.2

mNMO With IP_Conf0 set to manual, with this setting you can set a Netmask. Default is 255.255.0.0

mGWO With IP_Conf0 set to manual, this setting let you set a Standard Gateway. Default is set to 172.16.0.1

NetwPrefix0 Here you can set the proper network prefix if required.



6 Status Menu

Introduction

The status menu indicates the current status of each item listed below. There are no defaults for status indicators. Status depends of input signals being present or not.

sInp1

This status item indicates the presence and format of a valid signal in input 1. This is displayed as:

- 1080P60
- 1080p50
- NA

IO-Delay

Displays the total delay in ms between the Input and Output.

Value between 20ms and 160ms.

Ref

Displays whether a correct reference is found (Present) or not (NA)

NET STATUS

IP_Addr0

This item displays the status of the IP address. It can be manual, DHCP asking, DHCP Leased or DHCP Infin.

Mac0

This item displays the MAC address of the card.

IPO

This item displays the current IP address of the card.

NMO

This item displays the current Netmask of the card.

GWO

This item displays the current Standard Gateway of the card.

7 Events Menu

| | |
|---|---|
| Introduction | An event is a special message that is generated on the card asynchronously. This means that it is not the response to a request to the card, but a spontaneous message. |
| What is the Goal of an event? | The goal of events is to inform the environment about a changing condition on the card. A message may be broadcast to mark the change in status. The message is volatile and cannot be retrieved from the system after it has been broadcast. There are several means by which the message can be filtered. |
| Events | The events reported by the U4U100 are as follows; |
| Announcements | Announcements is not an event. This item is only used for switching the announcement of status changes on/off. 0=off, other =on |
| Ref-Status | Reference status can be selected between 0 .. 255. 0= no event, 1..255 is the priority setting. Default is Off. |
| What information is available in an event? | <p>The message consists of the following items;</p> <ol style="list-style-type: none"> 1) A message string to show what has happened in text, for example: “INP_LOSS”, “REF_LOSS”, “INP_RETURN”. 2) A tag that also shows what happens, but with a predefined number: e.g. 1 (= loss of input), 2 (= loss of reference), 129(= 1+128 = return of input). For a list of these predefined tags see the table on the next page. 3) A priority that marks the importance of an event. This value is defined by the user and can have any value between 1 and 255, or 0 when disabled. 4) A slot number of the source of this event. |
| The Message String | The message string is defined in the card and is therefore fixed. It may be used in controlling software like Synapse Set-up to show the event. |
| The Tag | The tag is also defined in the card. The tag has a fixed meaning. When controlling or monitoring software should make decisions based on events, it is easier to use the tag instead of interpreting a string. The first implementation is the tag controlled switch in the GPI16. In cases where the event marks a change to fault status (e.g. 1 for Loss of Input) the complement is marked by the tag increased by 128 (80 _{hex}) (e.g. 129 (81 _{hex}) for Return of Input). |



Defining Tags

The tags defined for the card are:

| Event Menu Item | Tag | Tag | Description |
|-----------------|---------------------------------|---------------------------------|---|
| Announcements | 0 or NA | 0 or NA | Announcing of report and control values |
| Input_A | 01 _{hex} =INP_LOST | 81 _{hex} =INP_RETURN | SDI input A lost or returned |
| Lock-status_A | 11 _{hex} =PLL_LOCKED | 91 _{hex} =PLL_UNLOCKED | PLL input A locked or unlock |
| Input_B | 12 _{hex} =INP_LOST | 92 _{hex} =INP_RETURN | SDI input B lost or returned |
| Lock-status_B | 51 _{hex} =PLL_LOCKED | d1 _{hex} =PLL_UNLOCKED | PLL input B locked or unlock |
| Active_Out_A | 19 _{hex} =IN_B_-_OUT_A | 99 _{hex} =IN_A_-_OUT_A | Active output A is In B or In A |
| Active_Out_B | 1a _{hex} =IN_A_-_OUT_B | 9a _{hex} =IN_B_-_OUT_B | Active output B is In A or In B |

The Priority

The priority is a user-defined value. The higher the priority of the alarm, the higher this value. Setting the priority to Zero disables the announcement of this alarm. Alarms with priorities equal or higher than the Error Threshold setting of the RRC will cause the error LED on the Synapse rack front panel to light.


The Address

Together with the message string or the tag, the slot number or address of the card is relevant to be able to assign the event to a certain card.

8 LED Indication

| | |
|-----------------------|--|
| Error LED | The error LED indicates an error if the internal logic of the card is not configured correctly or has a hardware failure. |
| Input_1 LED | This LED indicated the presence of a valid SDI video signal on input 1. |
| Reference LED | Indicated the presence of a valid reference signal on the selected reference input connector (ref-1 or ref-2). |
| Connection LED | This LED illuminates after the card has initialized. The LED lights for 0.5 seconds every time a connection is made to the card. |
| Error LED | The error LED indicates an error if the internal logic of the card is not configured correctly or has a hardware failure. |


9 Block Schematic



10 Connector Panels

The U4D100 can be used with the BPH17





Corporate
+32 4 361 7000

North & Latin America
+1 973 575 7811

Asia & Pacific
+852 2914 2501

Other regional offices
www.evs.com/contact

EVS Headquarters
Liège Science Park
13, rue Bois St Jean
B-4102 Seraing
Belgium



To learn more about EVS go to www.evs.com

EVS Broadcast Equipment is continuously adapting and improving its products in accordance with the ever changing requirements of the Broadcast Industry.
The data contained herein is therefore subject to change without prior notice. Companies and product names are trademarks or registered trademarks of their respective companies.