



GDS010

HDS010

3Gb/s, HD and SD basic down-converter and
synchronizer

Installation and Operation manual

Upgradable to
3Gb/s

**MASTER
Card**

AFD ready
S2016

3 TRIPLE RATE
GB/s, HD, SD

 **Powered
by LINUX**



Synapse

TECHNICAL MANUAL

GDS010
HDS010



**Lange Wagenstraat 55
NL-5126 BB Gilze
The Netherlands
Phone: +31 161 850 450
Fax: +31 161 850 499
E-mail: Info@axon.tv
Web: www.axon.tv**



WARNING: TO REDUCE THE RISK OF FIRE OR ELECTRICAL SHOCK, DO NOT EXPOSE THIS APPLIANCE TO RAIN OR MOISTURE

- ALWAYS disconnect your entire system from the AC mains before cleaning any component. The product frame (SFR18 or SFR04) must be terminated with three-conductor AC mains power cord that includes an earth ground connection. To prevent shock hazard, all three connections must always be used.
- NEVER use flammable or combustible chemicals for cleaning components.
- NEVER operate this product if any cover is removed.
- NEVER wet the inside of this product with any liquid.
- NEVER pour or spill liquids directly onto this unit.
- NEVER block airflow through ventilation slots.
- NEVER bypass any fuse.
- NEVER replace any fuse with a value or type other than those specified.
- NEVER attempt to repair this product. If a problem occurs, contact your local Axon distributor.
- NEVER expose this product to extremely high or low temperatures.
- NEVER operate this product in an explosive atmosphere.

Warranty: Axon warrants their products according to the warranty policy as described in the general terms. That means that Axon Digital Design BV can only warrant the products as long as the serial numbers are not removed.

Copyright © 2001 – 2015 AXON Digital Design B.V.

Date created: 16-12-2009

Date last revised: 06-11-2015

Axon, the Axon logo and Synapse are trademarks of Axon Digital Design B.V.

This product complies with the requirements of the product family standards for audio, video, audio-visual entertainment lighting control apparatus for professional use as mentioned below.



EN60950	Safety
EN55103-1: 1996	Emission
EN55103-2: 1996	Immunity

Axon Digital Design
GDS010
HDS010



Tested To Comply
With FCC Standards

FOR HOME OR OFFICE USE

This device complies with part 15 of the FCC Rules
Operation is subject to the following two conditions:
(1) This device may cause harmful interference, and
(2) This device must accept any interference received, including interference that may cause undesired operation.

Table of Contents

Introduction to Synapse	5
An Introduction to Synapse	5
Local Control Panel	5
Remote Control Capabilities	5
Unpacking and Placement	6
Unpacking	6
Placing the card	6
A Quick Start	7
When Powering-up	7
Changing settings and parameters	7
Front Panel Control	7
Example of changing parameters using front panel control	8
Synapse Cortex Software	9
Menu Structure Example	9
The GDS010 Card	10
Introduction	10
Features	10
Conversion capabilities	11
Applications	11
Block schematic	12
Important notice	12
Settings Menu	13
Introduction	13
IO-Ctrl	13
IO_Prst_Act	13
IO_Prst_Edit	13
#Inp_SelA	14
#Out-Ctrl	14
#Out-Frmt	14
#IO_Map	14
#V-delay	14
#H-delay	14
#Freeze_A	15
#LowPassFilt_A	15
Pos-Prst_Act	16
Pos-Prst_Edit	16
#H-Pos-A	16
#V-Pos-A	16
#VANC_Trans	17
#VANC_Trans_Ln0 ~ #VANC_Trans_Ln5	17
Delay-Status	17
Lock-Mode	17
Ref-Type	17
PrstEditView	17
PatternSpeed	17
Input_Loss_A	18
Dn_CtrlA	18
Dn_Prst_actA	18
Dn_Prst_editA	18
#Dn_ArcA	18
#Dn_H-scaleA	19
#Dn_V-scaleA	19
#Dn_H-EnhA	19
#Dn_ColorConvA	19
Tr_CtrlA	19
Tr_Prst_ActA	19
Tr_Prst_EditA	19
#Tr_ArcA	20
#Tr_H-scaleA	20
#Tr_V-scaleA	20
#Tr_H-EnhA	20
Timecode_Inp	20
VITC_Ln_In	20

VITC_Ln_Ctrl	20
VITC_Ln_625	21
VITC_Ln_525	21
VITC_Ln_Dup	21
ATC_Dem_Sel	21
ATC_Emb_Sel	21
Aux_TC_SRC	22
AUX_Dem_Sel	22
AUX_Emb_Sel	22
Aux_VITC_Ln_In	22
Ins_CtrlA	22
Ins_Prst_ActA	22
Ins_Prst_EditA	22
#VI-InsertA	23
#VI-DataA	23
#WSS-InsertA	23
#WSS-StndA	23
#WSS-ExtndA	23
#S2016-InsertA	23
#S2016-DataA	23
#CC_Ena_A	23
GainA	23
R-GainA	23
G-GainA	24
B-GainA	24
BlackA	24
R-BlackA	24
G-BlackA	24
B-BlackA	24
CVBS-Hue	24
Audio-Bus-IO	24
Audio_Ctrl	24
Audio_Prst_act	24
Audio_Prst_Edit	25
#EmbA_Grp	25
#EmbA1_Inp ~ #EmbA4_Inp	25
#EmbB_Grp	25
#EmbB1_Inp ~ #EmbB4_Inp	25
#EmbC_Grp	25
#EmbC1_Inp ~ #EmbC4_Inp	26
#EmbD_Grp	26
#EmbD1_Inp ~ #EmbD4_Inp	26
#EmbD1_Inp_Ch ~ #EmbD4_Inp_Ch	26
Contact_1 ~ Contact_5	26
GPI_A-mode ~ GPI_C-mode	27
GPI_A-Take ~ GPI_C-Take	27
IP_Conf0	27
mIP0	27
mNM0	27
mGW0	27
NetwPrefix0	27
Status Menu	28
Introduction	28
sInp1	28
sInp1_VI	28
sInp1_WSS-Stnd	29
sInp1_WSS-Extnd	29
sInp1_S2016	30
sInp1_CRC_EDH	30
sInp1-Map	30
IODelayA	30
FunctionA	30
Ref	30
Contact_Status	30
GPIA	31
GPIB	31
GPI_C	31
OP47-Det-A	31
WST-Det-A	31
CC_Det_A	31
SDI1DemFrmt01/02 ~ SDI1DemFrmt15/16	31
IP_Addr0	31
MAC0	31

IPO	31
NMO	31
GW0	31
Events Menu	32
Introduction	32
What is the Goal of an event?	32
Events	32
Announcements	32
Input_A	32
Ref-Status	32
What information is available in an event?	32
The Message String	32
The Tag	33
Defining Tags	33
The Priority	33
The Address	33
LED Indication	34
Error LED	34
Input_A LED	34
Input_B LED	34
ANC Data LED	34
Reference LED	34
Data Error LED	34
Connection LED	34
Error LED	34
Block Schematic	35
Connector Panels	36
GPI pinning	36
Card dip-switches for BHX and fiber configuration	37
Using BPH17 with fiber I/O	37
Using BHX17b	37
GPI's explained	39
Introduction	39
General functionality	39
Contact assignment	39
Pools	39
Take	40
Debounce time	40
Pool Mode: GPI	40
Pool Mode: GPO	41
Statuses: Contact direction	41
Statuses: Contact status	42
Statuses: GPI status	42
Statuses: GPO status	42
Example 1: Two pools in binary mode	42
Example 2: One pool in binary mode and one in priority mode	43
Example 3: Two pools in priority mode	43
GNU Public License version 2	45

1 Introduction to Synapse

An Introduction to Synapse

Synapse is a modular system designed for the broadcast industry. High density, intuitive operation and high quality processing are key features of this system. Synapse offers a full range of converters and processing modules. Please visit the AXON Digital Design Website at www.axon.tv to obtain the latest information on our new products and updates.

Local Control Panel

The local control panel gives access to all adjustable parameters and provides status information for any of the cards in the Synapse frame, including the Synapse rack controller. The local control panel is also used to back-up and restore card settings. Please refer to the RRC18, RRC10, RRC04, RRS18 and RRS04 manuals for a detailed description of the local control panel, the way to set-up remote control over IP and for frame related settings and status information.

Remote Control Capabilities

The remote control options are explained in the rack controller (RRC18/RRC10/RRC04/RRS18/RRS04) manual. The method of connection to a computer using Ethernet is described in the RRC/RRS manual.



CHECK-OUT: “SYNAPSE CORTEX” SOFTWARE WILL INCREASE SYSTEM FLEXIBILITY OF ONE OR MORE SYNAPSE FRAMES

Although not required to use Cortex with a Synapse frame, you are strongly advised to use a remote personal computer or laptop PC with Synapse Cotrtex installed, as this increases the ease of use and understanding of the modules.

2 Unpacking and Placement

Unpacking

The Axon Synapse card must be unpacked in an anti-static environment. Care must be taken NOT to touch components on the card – always handle the card carefully by the edges. The card must be stored and shipped in anti-static packaging. Ensuring that these precautions are followed will prevent premature failure from components mounted on the board.

Placing the card

The Synapse card can be placed vertically in an SFR18 frame or horizontally in an SFR04 and SFR08 frame. Locate the two guide slots to be used, slide in the mounted circuit board, and push it firmly to locate the connectors.

Correct insertion of card is essential as a card that is not located properly may show valid indicators, but does not function correctly.

NOTE: On power up all LED's will light for a few seconds, this is the time it takes to initialise the card.

NOTE: Please check appendix 2 before connecting any backpanel!

3 A Quick Start

When Powering-up


On powering up the Synapse frame, the card set will use basic data and default initialisation settings. All LED's will light during this process. After initialisation, several LED's will remain lit – the exact number and configuration is dependant upon the number of inputs connected and the status of the inputs.

Changing settings and parameters

The front panel controls or the Synapse Cortex can be used to change settings. An overview of the settings can be found in chapter 5, 6 and 7 of this manual.

Front Panel Control

Front Panel Display and Cursor



Settings are displayed and changed as follows;

Use the cursor 'arrows' on the front panel to select the menu and parameter to be displayed and/or changed.


- Press ► To go forward through the menu structure.
- Press ◀ To go back through the menu structure.
- Press ▲ To move up within a menu or increase the value of a parameter.
- Press ▼ To move down through a menu or decrease the value of a parameter.

NOTE: Whilst editing a setting, pressing ► twice will reset the value to its default.

**Example of
changing
parameters using
front panel control**

With the display as shown below


```
RRC18 [Select Card]
>S01=SFS10
```



Pressing the ► selects the SFS10 in frame slot 01.

The display changes to indicate that the SFS10 has been selected. In this example the Settings menu item is indicated.

```
SFS10 [Select Menu]
>Settings
```



Pressing the ► selects the menu item shown, in this example Settings.

(Pressing ▲ or ▼ will change to a different menu eg Status, Events).

The display changes to indicate that the SFS10 Settings menu item SDI-Format has been selected and shows that its current setting is Auto.

```
SFS10 [Settings]
>SDI-Format=Auto
```




Pressing the ► selects the settings item shown, in this example SDI-Format.

(Pressing ▲ or ▼ will change to a different setting, eg Mode, H-Delay).

The display changes to indicate that the SFS10 Edit Setting menu item SDI-Format has been selected.

```
SFS10 Edit Setting]
SDI-Format>Auto
```



To edit the setting of the menu item press ▲ or ▼.

All menu items can be monitored and/or changed in this way. Changing a setting has an immediate effect.



Synapse Cortex Software

Synapse Cortex can be used to change the settings of Synapse modules from a PC, either locally or remotely. The software enables communication based on TCP/IP between the Setup PC and Synapse frames/modules.

Each Synapse frame is addressed through its rack controller's unique IP address, giving access to each module, its menus and adjustment items. Synapse Cortex has access to data contained within the Synapse module and displays it on a GUI. The software has an intuitive structure following that of the module that it is controlling.

For operation of Synapse Cortex, please refer to the Cortex manual.

Menu Structure Example

Slot	Module	Item	Parameter	Setting
▲				
▲				
S02		Identity		
▲		▲		
S01	SFS10	▶ Set-tings	▶ Standard_dig	▶ Auto
▼		▼	▼	▼
S00	RRC18	Status	Mode	625
		▼	▼	▼
		Events	Ref-Input	525
			▼	
			H-Delay	
			▼	
			▼	

NOTE: Further information about Front Panel Control and Synapse Cortex can be obtained from the RRC and RRS operational manuals and the Cortex help files.

4 The GDS010 Card

Introduction

The GDS010 and HDS010 are *low latency* down converters with 16 channel audio transparency. The powerful matrix multiplexer can feed audio from the embedded domain into the Synapse bus to an ADD-ON card like the DIO48. This matrix multiplexer also allows for audio to be inserted from the ADD-ON bus into the embedded domain of the GDS010 or HDS010.

The GDS010 is compatible with 270Mb/s, 1.5Gb/s and 3Gb/s for full 1080p/50 or 1080p/59.94 use. The HDS010 are compatible with SD-SDI (270Mb/s) and HD-SDI (1.5Gb/s) and can be future upgraded to 3Gb/s compatibility

Features

- Low latency conversion process (as low as 1 field in controlled timing environment)
- Compatible with the following input and output formats (auto selecting) (1080p only for GDS) (only one standard can be chosen for both outputs simultaneously):

▪ 1080p/59.94	▪ 720p/59.94
▪ 1080p/50	▪ 720p/50
▪ 1080i/59.94	▪ 720p/23.98
▪ 1080i/50	▪ SD525
▪ 1080p/23.98	▪ SD625
▪ 1080psf/23.98	
- Frame sync with output phase control in Lines and pixels with respect to reference.
- All ARC modes contain:

▪ Center Cut	▪ PBox-4:3
▪ V-Zoom	▪ PBox-14:9
▪ LBox-16:9	▪ Variable H and V (50—200%)
▪ LBox-14:9	
- Free individual programmable presets banks for:

▪ Down converter ARC	16-presets
▪ VI insertion	16-presets
▪ WSS insertion	16-presets
▪ S2016 insertion	16-presets
- 5 GPI inputs assignable to different preset banks
 - Down conversion aspect ratio
 - Insertion of VI, WSS and AFD (S2016)
- ARC triggers by VI, WSS, WSSext and S2016 (AFD)
- Color corrector
- Transparent for 16 channels of embedded audio
- Video proc-amp
- Color corrector (RGB and total gain, RGB and total black)
- Hue control for NTSC inputs
- Locks to Bi-level syncs or SDI input
- OP47 to WST cross conversion
- Timecode cross conversion
- Auxiliary timecode input, allowing for 2 separate timecodes
- CC-708 to CC-608 conversion
- 6 Line Vertical Ancillary Blanking transparency in transparent mode
- Full control and status monitoring through the front panel of the SFR04/SFR08/SFR18 frame and the Ethernet port (ACP)

Conversion capabilities


CONVERSION		Output										
		1080psf23.97	1080p23.97	1080p50*	1080p59.94*	1080i59.94	1080i50	720p59.94	720p50	720p23.98	480i59.94(525)	576i50(625)
SDI Input	1080psf23.97	x									x	
	1080p23.97		x								x	
	1080p50*			x								x
	1080p59.94*				x						x	
	1080i59.94					x					x	
	1080i50						x					x
	720p59.94							x			x	
	720p50								x			x
	720p23.98									x	x	
	480i59.94(525)										x	
	576i50(625)											x

* = GDS models only

Applications

- Truck input down converter/synchronizer
- Infra structure down conversion

Block schematic



Important notice

Historically, closed captions were transmitted in NTSC line 21 according to EIA-608. This allows two caption data bytes per field to be transmitted. With the introduction of HD and DTV a new Closed Caption specification was made, EIA-708. This allows sending more data per field, for extended language, color support, PMT and EIT and timecode data.

The new DTV caption format cannot be translated back to EIA-608. However the EIA-708 may include EIA-608 data as "NTSC closed captions" for compatibility with old decoders.

This card only de-embeds the NTSC closed captions, not the DTV closed captions. It will not function with a DTV-only 708 closed caption source.

5 Settings Menu

Introduction

The settings menu displays the current state of each GDS-HDS010 setting and allows you to change or adjust it. Settings can be changed using the front panel of the Synapse frame (SFR18, SFR08 or SFR04) or with Cortex. Also the SCP08 control can be used. Please refer to chapter 3 for information on the Synapse front panel control and Cortex.

Note: All items preceded with a #-sign are part of the presets.

SYSTEM SETTINGS

IO-Ctrl

This card has separate presets for the input and output settings under the 'SYSTEM SETTINGS' header. With this item you select how the IO presets are controlled: Manually (manual, default), via GPI-triggers (GPI, GPI-A, GPI-B or GPI-C) or by the input format (SDI1-Format). The input formats are mapped to the presets as followed:

Format:	Preset:
1080i60	Preset 1
1080i50	Preset 2
1080p30	Preset 3
1080p25	Preset 4
1080p24	Preset 5
720p60	Preset 7
720p50	Preset 8
720p30	Preset 9
720p25	Preset 10
720p24	Preset 11
SD525	Preset 12
SD625	Preset 13
1080p50	Preset 14
1080p60	Preset 15

IO_Prst_Act

With this item you can manually change the currently active IO settings. Can be any preset between 1 and 8. By default it is set to 1. All menu settings that are preceded with a '# '-prefix under the 'SYSTEM SETTINGS' header are part of the preset.

IO_Prst_Edit

Here you can select which of the 8 selectable IO settings presets you want to edit. Changing this will not change the active preset, unless the currently active preset is the same you are going to edit. All menu settings that are preceded with a '# '-prefix under the 'SYSTEM SETTINGS' header are part of the preset.

#Inp_SelA	With this item you can select which input you want to use for Channel A. Can be SDI-1 (SDI input 1), a Zoneplate or Colorbar. Can also be set to Off to switch off channel A entirely. The default for this setting is SDI-1.
#Out-Ctrl	This setting controls the output format of the card. When set to Manual, the output format corresponds to the Out-Frmt setting. When set to Auto, the output format follows the input format. Possible settings are: <ul style="list-style-type: none">▪ Manual (default)▪ Auto
#Out-Frmt	With Out-Frmt you can set what the output should be. Possible settings are: <ul style="list-style-type: none">▪ 1080i60 (default), 1080i50▪ 1080p50, 1080p60▪ 1080p24▪ 1080psf24▪ 720p60, 720p50▪ 720p24▪ SD525, SD625
#IO_Map	With this setting you can configure the output as LevelA or LevelB (according to SMPTE S425) when the output format is 1080p50 or 1080p60.
#V-delay	V-Delay setting allows adjustment of the vertical phase of the output signal with respect to the selected reference input. The V-Delay setting gives a delay in addition to the reference timing. For example: if the V-Delay is set to 10 TV HD lines, the output signal will be delayed by reference timing + 10 TV HD lines. The signal is delayed (advanced) with respect to the phase of the reference signal. The available range is from 0 to a maximum of 1125 lines (dependant on I/O format). The default setting is 0ln. The preset master for this is Out-Frmt, hence the '#'-prefix.
#H-delay	The H-Delay setting allows adjustment of the Horizontal phase of the output signal with respect to the selected reference input. The H-Delay setting gives a delay in addition to the reference timing. For example: if the H-Delay is set to 10 pixels, the output signal will be delayed by reference timing + 10 pixels. The signal is delayed (advanced) with respect to the phase of the reference signal. The available range is from 0 to a maximum of 5124 pixels (dependant on I/O format). The default setting is 0px. The preset master for this is Out-Frmt, hence the '#'-prefix.


#Freeze_A

Freeze enables the capture of one Video Frame. The settings of Freeze are On or Off. The default setting is Off.


#LowPassFilt_A

Here you can set the horizontal and vertical video low-pass filter for channel A. These are the possible settings:

- Off: the normal broadband filters will be used when the card is converting. A 64 taps brick wall type horizontal filter:



- H_only: a less steep filter with no aliasing Y and soft for C for less ringing effects:



- V_only: vertical filters will be active which “soften” the image and prevents “ring”-effects in down converted content.
- H_And_V: same horizontal filter as described under H_Only will be active, together with the vertical filters described under V_only.

- H2_Only: less steep filter with aliasing and soft for C for less ringing, more sharpness but with aliasing:



- H2_And_V: same horizontal filter as described under H2_Only will be active, together with the vertical filters described under V_only.

Note: When the card is in **transparent** mode, the filters will be entirely bypassed.

Pos-Prst_Act

Active preset control for the position controls #H-Pos-A and #V-Pos-A. With this item you can manually change the currently active positioning settings. Default setting is 1.

Pos-Prst_Edit

Edit preset control for the position controls #H-Pos-A and #V-Pos-A. Here you can select which of the 8 selectable positioning settings presets you want to edit. Default setting is 1.

#H-Pos-A

Controls the horizontal positioning offset in pixels for channel A. Only works correctly when zooming in, for instance when downconverting using Center-Cut aspect ratio conversion.

#V-Pos-A

Controls the vertical positioning offset in pixels for channel A. Only works correctly when zooming in, for instance when downconverting using Center-Cut aspect ratio conversion.

#VANC_Trans	Enables or disables the transfer from input to output of selected Vertical Ancillary (VANC) lines. When the input format is the same as the output format, the card is able to carry up to 6 lines containing packets inserted in the Luminance Channel of the Vertical Ancillary space to the output. With settings #VANC_Trans_Ln0 to #VANC_Trans_Ln5 the user may select which lines to carry through to the output. The possible settings of #VANC_Trans are On or Off. The default setting is Off.
#VANC_Trans_Ln0	Selects a line to carry from input to output. You can choose 5 lines.
#VANC_Trans_Ln1	Refer to #VANC_Trans. Can be any line from line 7 through 41.
#VANC_Trans_Ln2	Refer to #VANC_Trans. Can be any line from line 7 through 41.
#VANC_Trans_Ln3	Refer to #VANC_Trans. Can be any line from line 7 through 41.
#VANC_Trans_Ln4	Refer to #VANC_Trans. Can be any line from line 7 through 41.
#VANC_Trans_Ln5	Refer to #VANC_Trans. Can be any line from line 7 through 41.
Delay-Status	It is possible to display (in the status menu IODelayA and IODelayB) the processing time of the card in the status menu. This setting allows you to switch this function ON or OFF. Default setting is OFF
Lock-Mode	Lock-Mode determines whether the card is locked to his input (input 1), to the reference (Ref1 or Ref2) or freerun (not locked). By default it is set to Ref1. Can also be set to RefAuto. When set to RefAuto the card chooses ref1 as its source. Whenever ref1 fails, it will switch to ref 2 (only for SFR08 and SFR18 frames and only when ref2 offers the same ref format as ref 1). When ref 1 is back up again, it will only automatically switch back to ref 1 when ref 2 fails.
Ref-Type	Sets the type of incoming reference. Can be either Bi-Level or Tri-Level. Default is Bi-Level.
PrstEditView	With this setting set to Follow Active, the edit preset settings (like for instance Dn_Prst_editA) will follow the active preset when the active preset is changed. This to avoid confusion when changing the active. Set to Independent the edit preset will not automatically follow active preset changes. By default set to Follow Active.
PatternSpeed	Sets the speed of the test-pattern (see settings Inp_SelA and Inp_SelB) animation between 0 (still) and 15 (fast). Default is 1.

Input_Loss_A

Here you can set what the output of channel A should be when the input is lost. Can be Freeze, Colorbar, Zoneplate, Black, Grey or Green.

DOWN-CONV

Dn_CtrlA

With this item you select how the presets are controlled in down converter mode: Manually (manual), via GPI-triggers (GPI, GPI-A, GPI-B or GPI-C) or via changes of the HD Aspect Ratio (S2016). By default it is set to Manual.

Dn_Prst_actA

With this item you can manually change the currently active preset in down converter mode. Can be any preset between 1 and 16. By default it is set to 1. All menu settings that are preceded with a '#Dn'-prefix are part of the preset.

Dn_Prst_editA

Here you can select which of the 16 selectable presets you want to edit in down converter mode. Changing this will not change the active preset, unless the currently active preset is the same you are going to edit. All menu settings that are preceded with a '#Dn'-prefix are part of the preset.

#Dn_ArcA

With this item you set the ARC of the output in down converter mode. Can be Anamorphic, CenterCut, LBox-16:9, LBox-14:9 or Variable. The following table shows examples of the possible aspect ratios when the input source is 16:9.

Setting:	Result on 4:3 screens:
Anamorphic	
CenterCut	
LBox-16:9	
LBox-14:9	
Anam-702	Anamorphic scaling based on 702 active pixels instead of 720 pixels
Variable	Dependant on Dn_H-scale and Dn_V-scale settings.

#Dn_H-scaleA The horizontal scaling of the TV picture in down converter mode is set using #Dn_H-scaleA. #Dn_H-scaleA can be set within the range of 50% to 200% of the input signal (only used when #Dn_ArcA is set to variable). Default value is 100%.

#Dn_V-scaleA Sets the vertical scaling of the TV picture in down converter mode. Can be set within the range of 50% to 200% of the input signal (only used when #Dn_ArcA is set to variable). Default value is 100%.

#Dn_H-EnhA With this item you can set the horizontal picture enhancement in down converter mode between 0 and 100%. By default set to 0%.

#Dn_ColorConvA ColorConvA optimizes the color conversion in down converter mode. As the color coding of HD (709) and SD (601) are different, it is necessary to convert these when Channel A is up-converting. The best result is generated when the up-converter is active and the 709to601 setting is selected. It is also possible to switch the filter off. The default setting is Off.

TRANSPARENT


Tr_CtrlA With this item you select how the presets are controlled in Transparent mode: Manually (manual), via GPI-triggers (GPI, GPI-A, GPI-B or GPI-C) or via changes of the HD Aspect Ratio (S2016). By default it is set to Manual.

Tr_Prst_ActA With this item you can manually change the currently active preset in Transparent mode. Can be any preset between 1 and 16. By default it is set to 1. All menu settings that are preceded with a '#Tr'-prefix are part of the preset.

Tr_Prst_EditA Here you can select which of the 16 selectable presets you want to edit in Transparent mode. Changing this will not change the active preset, unless the currently active preset is the same as the one you are going to edit. All menu settings that are preceded with a '#Tr'-prefix are part of the preset.

#Tr_ArcA

With this item you set the Aspect Ratio of the output in Transparent mode. Can be *Anamorphic* or *Variable* (custom set AR, set by H-scale and V-scale settings). The following table shows examples of the possible aspect ratios.

Setting:	Result:
Anamorphic	 <p>With 16:9 source on 4:3 screens</p>
Variable	Dependant on Tr_H-scale and Tr_V-scale settings.

#Tr_H-scaleA

The horizontal scaling of the TV picture in Transparent mode is set using #Tr_H-scaleA. #Tr_H-scaleA can be set within the range of 50% to 200% of the input signal (only used when #Tr_ArcA is set to *variable*). Default value is 100%.

#Tr_V-scaleA

Sets the vertical scaling of the TV picture in Transparent mode. Can be set within the range of 50% to 200% of the input signal (only used when #Up_ArcA is set to *variable*). Default value is 100%.

#Tr_H-EnhA

With this item you can set the horizontal picture enhancement in Transparent mode between 0 and 100%. By default set to 0%.

INSERTER

This card can insert several data values in the VBI of the outputs. With the following settings you can choose what you want to insert.

Timecode_Inp

With this card it is possible to copy the embedded timecode information of either input SDI-1 or input SDI-2 to the output. With this setting you select which input you want to use, or switch the timecode inserting *Off* (default).

VITC_Ln_In

With this setting you can select what line of the input you want to copy the VITC data from (only when input is SD). Can be any line between line 7 and line 22. Default is line 19.

VITC_Ln_Ctrl

Here you can choose whether you want to select the line, to where you want to copy the timecode data to, manually (*manual*) or use the information in the ATC_DBB package to select the lines (ATC_DBB package contains information about the line duplication as well). Default is *Manual*.

VITC_Ln_625	When <code>VITC_Ln_Ctrl</code> is set to Manual, with this setting you can select a line between 7 and 22 when the output is SD625. Default is line 19.
VITC_Ln_525	When <code>VITC_Ln_Ctrl</code> is set to Manual, with this setting you can select a line between 7 and 22 when the output is SD525. Default is line 10.
VITC_Ln_Dup	set to On, the VITC line is duplicated to the above selected line + 2 .
ATC_Dem_Sel	ATC source de-embed selection. Previously, the first ATC found in a field would be transcoded to the output. Now, the user can select whether to de-embed LTC, VITC or the first ATC found.
ATC_Emb_Sel	ATC_Emb_Sel: ATC destination embed selection. Previously, timecode was transcoded into VITC. Now the user can select whether to transcode to VITC or LTC.

AUXILIARY TIMECODE

An additional (Auxiliary) timecode input functionality is available. The original timecode from the source is still carried through to the output. If applicable given the conversion the card is performing, the timecode is translated from VITC to ATC or viceversa.

The Auxiliary timecode source can be selected (`Aux_TC_SRC`) from any video source on the card. Like the original timecode, it is translated from VITC to ATC or viceversa if applicable, so the type of timecode matches the output format of the card. The timecode is delayed according to the `Aux_TC_DLY` setting.

Because devices need to be able to distinguish between the two timecodes, devices need to be able to handle both the timecodes. When VITC is inserted into an SD signal, both timecodes can be inserted into different lines. For instance, when SD625 is set as the output format, the original timecode gets inserted into the line set by `VITC_Ln_625`. The auxiliary timecode is inserted into the line set by `Aux_Ln_625`. When SD525 is set as the output format, both timecodes are inserted according to settings `VITC_Ln_525` and `Aux_Ln_525`.

When the output is set to any HD or 3Gb/s format, the timecode is inserted as an ATC packet. The user can select whether to insert the timecode packet as LTC, or as VITC. This is controlled by setting `ATC_Emb_Sel` for the original timecode, and setting `AUX_Emb_Sel` for the auxiliary timecode. Because these are inserted into different lines, devices can distinguish between the

	<p>two.</p> <p>The Axon devices can be set to de-embed either or any of the two, both for the original timecode input and the auxiliary timecode input. This can be set by <code>AUX_Dem_Sel</code> and <code>ATC_Dem_Sel</code>. When receiving an SD signal, the input line can be set separately for both normal timecode and auxiliary timecode, by <code>VITC_Ln_In</code> and <code>Aux_VITC_Ln_In</code>. The other applicable timecode settings, such as <code>VITC_Ln_Ctrl</code> and <code>VITC_Ln_Dup</code> control both the normal timecode insertion as well as the auxiliary timecode insertion.</p>
Aux_TC_SRC	With this setting you can set the timecode source of the second timecode inserter. Can be SDI-1, SDI-2, Analog input or Off.
AUX_Dem_Sel	Auxiliary ATC source de-embed selection. Previously, the first ATC found in a field would be transcoded to the output. Now, the user can select whether to de-embed LTC, VITC or the first ATC found.
AUX_Emb_Sel	Auxiliary ATC destination embed selection. Previously, timecode was transcoded into VITC. Now the user can select whether to transcode to VITC or LTC.
Aux_VITC_Ln_In	Auxiliary VITC read line. The Auxiliary timecode read line can differ from the normal VITC read line. This means, that from an SD source, two different timecode lines can be transcoded to the output.
Ins_CtrlA	With this item you select how the inserter presets are controlled: Manually (manual), via GPI-triggers (GPI, GPI-A, GPI-B or GPI-C), via changes of the SD Aspect Ratio (<code>SD_AR</code>) or the HD aspect ratio (S2016) (AFD)). Default is Manual.
Ins_Prst_ActA	With this item you can manually change the currently active inserter preset. Can be any preset between 1 and 16. By default it is set to 1. All menu settings that are preceded with a '#Ins'-prefix are part of the preset.
Ins_Prst_EditA	Here you can select which of the 16 selectable inserter presets you want to edit. Changing this will not change the active preset, unless the currently active preset is the same you are going to edit. All menu settings that are preceded with a '#Ins'-prefix are part of the preset.

#VI-InsertA You can turn VI insertion on or off. Default is Off.

#VI-DataA With the #VI-InsertA setting set to on, you can select VI values with this setting, which you want to be inserted in Channel A. possible are all VI values between 4:3_0 and 4:3_7 and the settings between 16:9_0 and 16:9_7. Default is 4:3_0.

#WSS-InsertA You can choose which type of WSS data you want to insert with this setting, or switch WSS insertion entirely off (default value). You can set it to Standard or Extended.

#WSS-StndA With the #WSS-InsertA setting set to Standard, you can select WSS standard values with this setting, which you want to be inserted in Channel A. possible are all WSS values between 1_vid and 8_vid and the settings between 1_flm and 8_flm. Default is 1_vid.

#WSS-ExtndA With the #VI-InsertA setting set to on, you can select VI values with this setting, which you want to be inserted. possible are all WSS values between 4:3_0 and 4:3_7 and the settings between 16:9_0 and 16:9_7. Default is 4:3_0.

#S2016-InsertA You can turn S2016 (AFD) insertion on or off for channel A. Default is Off.

#S2016-DataA With the #S2016-InsertA setting set to on, you can select AFD values with this setting, which you want to be inserted. possible are all AFD values between AFD0 and AFD15.

#CC_Ena_A This setting sets the Closed Captioning transparency for channel A On or Off. Default is Off.

VIDEO PROC

GainA With this setting you control the overall gain of the video between 50 and 150%. Default is 100%.

R-GainA R-GainA controls the Red gain. The control range is between 50% and 150%. The default setting is 100%.

G-GainA	G-GainA controls the Green gain. The control range is between 50% and 150%. The default setting is 100%.
B-GainA	B-GainA controls the Blue gain. The control range is between 50% and 150%. The default setting is 100%.
BlackA	BlackA controls the total R-G-B Black gain. The control range is between -128bit and 127bit. The default setting is 0bit.
R-BlackA	R-BlackA controls the Red-Black. The control range is between -128bits and 127 bits in steps of 1 bit. The default setting is 0 bit.
G-BlackA	G-BlackA controls the Green-Black. The control range is between -128bits and 127 bits in steps of 1 bit. The default setting is 0 bit.
B-BlackA	B-BlackA controls the Blue-Black. The control range is between -128bits and 127 bits in steps of 1 bit. The default setting is 0 bit.
CVBS-Hue	This item adjusts the HUE of the CVBS input. Can be set between -90 and +90 degrees. Default is 0 degrees.

AUDIO PROC AMP

Audio-Bus-IO	This setting can change the Audio bus order from the normal 1234 (=default) to 1324. The 1324 order is of use to route the 1 st group of audio from the 2 nd input to the 2 nd channel of a slave card (like the DIO48).
Audio_Ctrl	With this setting you select how the audio presets should be controlled. Can be either Manually (Manual), via GPI-triggers (GPI, GPI-A, GPI-B or GPI-C), via the SD aspect ratio (SD-AR) or via the HD aspect ratio (S2016).
Audio_Prst_act	With this item you can manually change the currently active audio preset. Can be any preset between 1 and 16. By default it is set to 1. All menu settings that are preceded with a '#Emb'-prefix are part of the preset.

Audio_Prst_Edit

Here you can select which of the 16 selectable audio presets you want to edit. Changing this will not change the active preset, unless the currently active preset is the same you are going to edit. All menu settings that are preceded with a '#Emb'-prefix are part of the preset.

EMBEDDER

#EmbA_Grp

With this setting you select in to which audio group (= 4 audio channels) of the outputs you want to embed the first 4 forwarded audio channels coming from the de-embedders/add-on bus. Can be `group1`, `group2`, `group3` or `group4`. You can also choose to not use these 4 audio channels for anything by setting this item to `off`. By default it is set to `Group1`.

#EmbA1_Inp ~ #EmbA4_Inp

With these settings you can select where the corresponding audio channels (channel A1 till channel A4) of the outputs are coming from. In this card you can only choose to get the audio from the de-embedder (`Demb-input`) or to mute the corresponding channel (set to `off`). Defaults here are `Off`.

#EmbB_Grp

With this setting you select in to which audio group (= 4 audio channels) of the outputs you want to embed the second 4 forwarded audio channels coming from the de-embedders/add-on bus. Can be `group1`, `group2`, `group3` or `group4`. You can also choose to not use these 4 audio channels for anything by setting this item to `off`. By default it is set to `Group2`.

#EmbB1_Inp ~ #EmbB4_Inp

With these settings you can select where the corresponding audio channels (channel B1 till channel B4) of the outputs are coming from. In this card you can only choose to get the audio from the de-embedder (`Demb-input`) or to mute the corresponding channel (set to `off`). Defaults here are `Off`.

#EmbC_Grp

With this setting you select in to which audio group (= 4 audio channels) of the outputs you want to embed the third group of 4 forwarded audio channels coming from the de-embedders/add-on bus. Can be `group1`, `group2`, `group3` or `group4`. You can also choose to not use these 4 audio channels for anything by setting this item to `off`. By default it is set to `Group2`.

**#EmbC1_Inp ~
#EmbC4_Inp**

With these settings you can select where the corresponding audio channels (channel C1 till channel C4) of the outputs are coming from. In this card you can only choose to get the audio from the de-embedder (Demb-input) or to mute the corresponding channel (set to off). Defaults here are Off.

#EmbD_Grp

With this setting you select in to which audio group (= 4 audio channels) of the outputs you want to embed the last 4 forwarded audio channels coming from the de-embedders/add-on bus. Can be group1, group2, group3 or group4. You can also choose to not use these 4 audio channels for anything by setting this item to off. By default it is set to Group2.

**#EmbD1_Inp ~
#EmbD4_Inp**

With these settings you can select where the corresponding audio channels (channel D1 till channel D4) of the outputs are coming from. In this card you can only choose to get the audio from the de-embedder (Demb-input) or to mute the corresponding channel (set to off). Defaults here are Off.

**#EmbD1_Inp_Ch ~
#EmbD4_Inp_Ch**

With these settings you can select which Channel of the selected input should be embedded to the corresponding output channel. Can be any channel between Ch_1 and Ch_16. Defaults for C1 till C4 are respectively Ch_13 till Ch_16.

GPI-CTRL

**Contact_1 ~
Contact_5**

In this card it is possible to make the 5 available GPI contacts part of a GPI pool that can control the various functions in the card separately (all Xx_Ctrl items of the menu). With these item you can select which pool the corresponding GPI is part of. You can also choose to not use the corresponding GPI at all by setting it to Off. Possible settings are:

- GPI A: part of GPI-A pool, triggered once Take A is closed.
- GPI B: part of GPI-B pool, triggered once Take B is closed.
- GPI C: part of GPI-C pool, triggered once Take C is closed.

Please refer to ‘Appendix 3: GPI’s explained’ for a more elaborate explanation of the GPI settings and status items.

**GPI_A-mode ~
GPI_C-mode**

Selects the mode for the corresponding GPI pool. Possible settings are:

- **Prio:** Each contact triggers another value, so values are one-hot encoded.
- **Prio_latched:** This mode functions like **Prio Mode**, but the card latches the value. Each contact triggers another value, so values are one-hot encoded. Use this mode when using pushbuttons.
- **Binary:** Values are coded in a binary fashion, with code “00000” coding for a starting value of 1, as can be seen in the GPI status items.

Please refer to ‘Appendix 3: GPI’s explained’ for a more elaborate explanation of the GPI settings and status items.

**GPI_A-Take ~
GPI_C-Take**

Selects a take contact for the corresponding GPI pool. Possible settings are:

- **Off:** No take contact is defined, and values on the GPI contact are taken instantly.
- **Contact_1 ~ Contact_5:** The selected contact is used as a Take command for the corresponding pool. Closing the selected contact results in the card latching the value provided on the selected contacts for that pool.

Please refer to ‘Appendix 3: GPI’s explained’ for a more elaborate explanation of the GPI settings and status items.

NETWORK

IP_Conf0

With this setting you can let the card obtain an IP address automatically via DHCP, or appoint a manual set IP address. By default this setting is set to `Manual`.

mIPO

When `IP_Conf0` is set to `manual`, you can type in the preferred IP address here. By default it is set to `172.16.1.2`

mNMO

With `IP_Conf0` set to `manual`, with this setting you can set a Netmask. Default is `255.255.0.0`

mGWO

With `IP_Conf0` set to `manual`, this setting let you set a Standard Gateway. Default is set to `172.16.0.1`

NetwPrefix0

Here you can set the proper network prefix if required.

6 Status Menu

Introduction The status menu indicates the current status of each item listed below.

sInp1 This status item indicates the presence and format of a valid signal in input 1. This is displayed as:

- 1080P60
- 1080p50
- 1080i60
- 1080i50
- 1080p30
- 1080p25
- 1080p24
- 1035i60
- 720p60
- 720p50
- 720p30
- 720p25
- 720p24
- SD525
- SD625
- NA

sInp1_VI Displays the detected VI value found in input1. This is displayed as follows:

- 4:3_0
- 4:3_1
- 4:3_2
- 4:3_3
- 4:3_4
- 4:3_5
- 4:3_6
- 4:3_7
- 16:9_0
- 16:9_1
- 16:9_2
- 16:9_3
- 16:9_4
- 16:9_5
- 16:9_6
- 16:9_7
- NA (no VI detected)

sInp1_WSS-Stnd

This status item displays the detected standard WSS value of input 1. this is displayed as follows:

- 1_vid
- 2_vid
- 3_vid
- 4_vid
- 5_vid
- 6_vid
- 7_vid
- 8_vid
- 1_flm
- 2_flm
- 3_flm
- 4_flm
- 5_flm
- 6_flm
- 7_flm
- 8_flm
- NA (no standard WSS detected)

sInp1_WSS-Extd

This item displays the detected extended WSS value of input 1. This is displayed as follows:

- 4:3_0
- 4:3_1
- 4:3_2
- 4:3_3
- 4:3_4
- 4:3_5
- 4:3_6
- 4:3_7
- 16:9_0
- 16:9_1
- 16:9_2
- 16:9_3
- 16:9_4
- 16:9_5
- 16:9_6
- 16:9_7
- NA (no WSS extended detected)

sInp1_S2016	<p>This item displays the detected SMPTE 2016 (AFD) values of input 1. This is displayed as follows:</p> <ul style="list-style-type: none"> ▪ AFD0 ▪ AFD1 ▪ AFD2 ▪ AFD3 ▪ AFD4 ▪ AFD5 ▪ AFD6 ▪ AFD7 ▪ AFD8 ▪ AFD9 ▪ AFD10 ▪ AFD11 ▪ AFD12 ▪ AFD13 ▪ AFD14 ▪ AFD15 ▪ NA (no S2016 detected)
sInp1_CRC_EDH	<p>This item indicates CRC and EDH errors on input 1. Can be:</p> <ul style="list-style-type: none"> ▪ Off ▪ OK ▪ Error ▪ NA ▪ NoPCM
sInp1-Map	<p>Displays the mapping of the 3Gb/s input, if the format is 1080p50 or 1080p60. Can be Level A or Level B. NA is indicated if the input is not 3Gb/s.</p>
IODelayA	<p>Displays the total delay in ms of outputs A1 and A2. can be a value between 0ms and 5000ms.</p>
FunctionA	<p>Displays the current function outputs A1 and A2. For the card it can only be Up, Trans, TestPattern or NA.</p>
Ref	<p>Displays whether a correct reference is found (Present) or not (NA)</p>
Contact_Status	<p>Displays the currently closed GPI contacts. This is displayed as for instance 10100 when contacts 1 and 3 are closed and for instance 01110 when contacts 2, 3 and 4 are closed.</p>

GPIA	Displays the current value of GPI pool A
GPIB	Displays the current value of GPI pool B
GPIC	Displays the current value of GPI pool C
OP47-Det-A	Displays whether or not there's OP47 detected on channel A
WST-Det-A	Displays whether or not there's WST (teletext) detected on channel A
CC_Det_A	Displays whether or not there's Closed Captioning detected on channel A
SDI1DemFrmt01/02 ~ SDI1DemFrmt15/16	<p>These status items indicate the detected audio format of each audio pair in the de-embedder of SDI input 1. Can be one of the following formats:</p> <ul style="list-style-type: none"> ▪ N/A ▪ PCM ▪ Null ▪ AC-3 ▪ TimeStmp ▪ MPEG-1 ▪ MPEG-2 ▪ SMPTE-KLV ▪ Dolby E ▪ Caption data ▪ UserDef ▪ Rsvd ▪ Enh Ac-3

NET STATUS

IP_Addr0	This item displays the status of the IP address. It can be manual, DHCP asking, DHCP Leased or DHCP Infin.
MAC0	This item displays the MAC address of the card.
IPO	This item displays the current IP address of the card.
NM0	This item displays the current Netmask of the card.
GW0	This item displays the current Standard Gateway of the card.

7 Events Menu

Introduction	An event is a special message that is generated on the card asynchronously. This means that it is not the response to a request to the card, but a spontaneous message.
What is the Goal of an event?	The goal of events is to inform the environment about a changing condition on the card. A message may be broadcast to mark the change in status. The message is volatile and cannot be retrieved from the system after it has been broadcast. There are several means by which the message can be filtered.
Events	The events reported by the card are as follows;
Announcements	Announcements is not an event. This item is only used for switching the announcement of status changes on/off. 0=off, other =on
Input_A	Input_A can be selected between 0 .. 255. 0= no event, 1..255 is the priority setting.
Ref-Status	Reference can be selected between 0 .. 255. 0= no event, 1..255 is the priority setting.
What information is available in an event?	<p>The message consists of the following items;</p> <ol style="list-style-type: none"> 1) A message string to show what has happened in text, for example: "INP_LOSS", "REF_LOSS", "INP_RETURN". 2) A tag that also shows what happens, but with a predefined number: e.g. 1 (= loss of input), 2 (= loss of reference), 129(= 1+128 = return of input). For a list of these predefined tags see the table on the next page. 3) A priority that marks the importance of an event. This value is defined by the user and can have any value between 1 and 255, or 0 when disabled. 4) A slot number of the source of this event.
The Message String	The message string is defined in the card and is therefore fixed. It may be used in controlling software like Synapse Set-up to show the event.

The Tag

The tag is also defined in the card. The tag has a fixed meaning. When controlling or monitoring software should make decisions based on events, it is easier to use the tag instead of interpreting a string. The first implementation is the tag controlled switch in the GPI16.

In cases where the event marks a change to fault status (e.g. 1 for Loss of Input) the complement is marked by the tag increased by 128 (80_{hex}) (e.g. 129 (81_{hex}) for Return of Input).

Defining Tags

The tags defined for the card are:

Event Menu Item	Tag		Description
Announcements	0 or NA	0 or NA	Announcement of report and control values
Input_A	01 _{hex} =INPA_LOSS	81 _{hex} =INPA_RETURN	input A lost or returned
Reference	03 _{hex} =REF_LOSS	83 _{hex} =REF_RETURN	reference lost or returned

The Priority

The priority is a user-defined value. The higher the priority of the alarm, the higher this value. Setting the priority to Zero disables the announcement of this alarm. Alarms with priorities equal or higher than the Error Threshold setting of the RRC will cause the error LED on the Synapse rack front panel to light.


The Address

Together with the message string or the tag, the slot number or address of the card is relevant to be able to assign the event to a certain card.

8 LED Indication


Error LED	The error LED indicates an error if the internal logic of the card is not configured correctly or has a hardware failure.
Input_A LED	This LED indicated the presence of a valid SDI video signal on input A.
Input_B LED	This LED indicated the presence of a valid SDI video signal on input B.
ANC Data LED	Indicates the presence of embedded audio within the input signal.
Reference LED	Indicated the presence of a valid reference signal on the selected reference input connector (ref-1 or ref-2).
Data Error LED	This LED indicates a CRC error.
Connection LED	This LED illuminates after the card has initialized. The LED lights for 0.5 seconds every time a connection is made to the card.
Error LED	The error LED indicates an error if the internal logic of the card is not configured correctly or has a hardware failure.

9 Block Schematic




10 Connector Panels

The GDS-HDS010 can be used with the BPH17 or the BHX17b. The following table displays the pinout of these backpanels in combination with the card.



!Unused inputs and outputs must be terminated with the correct impedance!

GPI pinning




Pin	Function
1	GPI in 1
2	GPI in 2
3	GPI in 3
4	GPI in 4
5	GPI in 5
6	GPI out 1
7	GPI out 2
8	Ground

Appendix 1 Card dip-switches for BHX and fiber configuration

There are dip-switches on the circuit board of the card itself. With these dip-switches you can change the power-voltages that is put on the backpanel. By default the switches are set to off, putting no power on the backpanel. The picture below displays where the switch is positioned on the card.



When using a ‘normal’ BPH17 (passive) backpanel with this card, the dipswitch on the card itself must be switched OFF.



Using BPH17 with fiber I/O

When using a BPH17 backpanel with fiber I/O, you must first set the **top-side** dip-switch on the **synapse board** to ‘on’. This will pass 30 volt to the backpanel. If this is not done, the relays won’t work at all.

Using BHX17b

When using the backpanel with bypass relay (BHX17b), you must first set the **bottom-side** dip-switch **on the card** to ‘on’. This will pass 5 volt to the backpanel. If this is not done, the relays won’t work at all.

On the BHX17b itself there are also 2 dipswitches (see picture on the next page). The bottom dipswitch is not connected. With the top switch you can choose the Bypass function. There are 2 possible function indications “on” (printed on the dip switch itself) and “off”:

“Direct Backpanel Switchover” dipswitch set to ON:

Will make the BHX-backpanel switch over to the processed signal as soon as it detects the trigger signal from the connected synapse card. This setting will minimize the bypass time and ensures fast recovery of processed signals.

The **ON** setting is recommended if the BHX-backpanel is used in combination with synapse cards:


- which have a short initialization time, or
- which have a delayed trigger-signal onboard.

“**Direct Backpanel Switchover**” dipswitch set to **OFF (default)**: Will make the BHX-backpanel switch after about 15 seconds from the moment the BHX-backpanel detects the trigger signal from the connected synapse card. This setting will allow more time for complex synapse cards to finish initialization and stabilize proper signal processing before the backpanel switches over to the processed signal.

The **OFF** setting is recommended if the BHX-backpanel is used in combination with synapse cards:

- which are more complex and thus need longer initialization time and do NOT have a delayed trigger-signal onboard.

Note: In case of power failure or when the synapse board is extracted from the frame the bypass is immediately active.



Appendix 3 GPI's explained

Introduction

This appendix describes the functionality of the GPI's generally used within the Synapse based products.

General functionality

The physical contacts of a General Purpose Interface can be assigned by the user. In our cards the General Purpose Interface contacts (GPI contacts) will be named as General Purpose Input (GPI) or General Purpose Output (GPO). The GPI inputs and outputs are assignable to different preset banks. These preset banks (GPI pools) can be used to switch multiple settings at once. Some examples of these functions:


- Input selection
- Output mode
- Up conversion aspect ratio for channel A and B
- Down conversion aspect ratio for channel A and B
- Cross conversion aspect ratio for channel A and B
- Transparent aspect ratio (equal in-output) for channel A and B
- Insertion of VI, WSS, AFD (S2016) for channel A and B
- Audio shuffling, gain and phase

Contact assignment

The physical contacts can be assigned as input or output. In the menu of a card, these will be called `Contact_N` depending on the amount of contacts available. Contacts could be Inputs, outputs or bi-directional I/O. The `Contact_N` menu item will be used to assign this specific contact to input or output pools. The choices are `Off`, `GPI_A`, `GPI_B`, `GPI_C`, ..., `GPI_N`, `GPO_A`, `GPO_B`, `GPO_C`, ..., `GPO_N` depending on the amount of contacts and pools.

Pools

A GPI/GPO pool is a place where contacts are collected to form an output trigger.



Take

The GPI contacts not only can be used as GPI contact but also can be assigned as Take contact. The menu item is called GPI_n-Take. Where n is the amount of GPI pools in the product. Every pool can only have one Take contact. There will be no restrictions in assigning the contact to a GPI pool and Take function at the same time. The values will be 1 to x. When assigning a take pin to a pool set to Prio_Latched mode, the pool will behave the same as when set to Prio mode with a take pin assigned. This is because the take pin overrules the latched functionality of the Prio_Latched mode.

Debounce time

The input contacts need to be debounced to assure signal stability. The debounce time can be set in the GPI-DebounceTime object in a range of 1-40 ms. This value will be applied to all contacts. In software implementations setting a custom debounce time is not supported due to technical limitations.

Pool Mode: GPI

Every GPI pool can be set up to process the input contacts in three ways. This setting is called GPI_n-Mode and can be set into priority (Prio), priority latched (Prio_Latched) and Binary mode. N is defined as a character in the range from A-Z depending on the number of pools. The default output value of a pool is always 0. This translates to preset 1 in Axon products. In priority mode, the contact which has the highest priority defines the pool value. Priority is defined as ranging from the least significant bit (low priority) to the most significant bit (high priority). This is essentially a one-hot coding of preset values. If a pool has three contacts connected and all inputs are high, the output value of the pool will be 3. Another example is when three contacts are connected to a pool with the first and third contact are low and the second contact is high the output value is 1.

Input 1	Input 2	Input 3	Pool value	Preset nr
0	0	0	1	1
1	0	0	1	1
X	1	0	2	2
X	X	1	3	3

Table 1 Pool value in prio and prio_latched mode


In binary mode, the contacts are interpreted as a binary value of concatenated contacts available in a pool. E.g. assigning two contacts to a GPI pool translates to the following output values.

Input 1	Input 2	Pool value	Preset nr
0	0	1	1
0	1	2	2
1	0	3	3
1	1	4	4

Table 2 Pool value in binary mode

Pool Mode: GPO

Every GPO pool can be set up to process the input values in two ways. This setting is called `GPO_n-Mode` and can be set into Priority (`Prio`) or Binary mode. `N` is defined as a character in the range from A-Z depending on the number of pools. The default output value of a pool is always 0.



Every GPO pool can be set up to process the input values in two ways. This setting is called `GPO_n-Mode` and can be set into Priority (`Prio`) or Binary mode. `N` is defined as a character in the range from A-Z depending on the number of pools. The default output value of a pool is always 0.

In priority mode, the value is translated to one-hot encoding on the output contacts. See table below.

Preset nr	Output 1	Output 2	Output 3	Pool value
1	1	0	0	1
2	0	1	0	2
3	0	0	1	3

Table 3 Pool value in priority mode

In binary mode the input value is exposed on the output contacts as binary value.

Preset nr	Output 1	Output 2	Pool value
1	0	0	1
2	0	1	2
3	1	0	3
4	1	1	4

Table 4 Pool value in binary mode

`GPO_n-Source` is the setting with which a function is assigned to a `GPO` pool. E.g. when the output format needs to be reflected on the output contacts, this setting may be set to something like `Output_Format`. The contents of the enumeration are product specific.

Statuses: Contact direction

This status `Contact-Dir` shows the direction of the physical contacts. The value will be presented as a concatenated string containing one character per pin: `I` for Input, `O` for output and `_` for unassigned contacts.

Statuses: Contact status

Contact-Status shows the current logical value of the physical contacts, formatted as a concatenated string containing one character per pin: 1 for asserted, 0 for non-asserted and _ for unassigned.

Statuses: GPI status

GPI_n is an integer which reflects the value of the pool.

Statuses: GPO status

GPO_n is an integer which reflects the value of the pool.

Example 1: Two pools in binary mode

We are controlling the up-converter presets using Pool A (Up_CtrlA set to GPI_A) and the output mode setting using Pool B (Out-mode-Ctrl set to GPI_B). Both pools are working in priority mode. The GPI's need to be set-up in the following way:

- Set GPI_A-Mode to Prio
- Set Contact_1 to GPI_A
- Set Contact_2 to GPI_A
- Set Contact_3 to GPI_A
- Set Contact_4 to GPI_A
- Set GPI_B-Mode to Prio
- Set Contact_5 to GPI_B

Pool A now consists of GPI 1, GPI 2, GPI 3 and GPI 4 in a priority mode, controlling the up-converter preset. Pool B consists only of GPI 5 (also in priority mode), controlling the output mode setting. Pool A now works as follows:

Cont act_1 statu s	Cont act_2 statu s	Conta ct_3 statu s	Conta ct_4 statu s	GPI_A value
0	0	0	0	Up-conv Preset 1
1	0	0	0	Up-conv Preset 1
0	1	0	0	Up-conv Preset 2
0	0	1	0	Up-conv Preset 3
0	0	0	1	Up-conv Preset 4
0	1	1	0	Up-conv Preset 3 (highest gets priority)
1	1	1	1	Up-conv Preset 4 (highest gets priority)

Table 5 Pool value in priority mode

Pool B now works as follows:

Contact_5 status	GPI_B value
0	A out only
1	B out only

Table 6 Pool value in priority mode

Example 2: One pool in binary mode and one in priority mode

Let's say we would like to control the GXG up-converter presets using Pool A (Up_CtrlA set to GPI_A) in binary mode and the audio presets using Pool B (Audio_Ctrl set to GPI_B) in priority mode. We could do the following:

- Set GPI_A-Mode to binary
- Set Contact_1 to GPI_A
- Set Contact_2 to GPI_A
- Set GPI_A-Take to Contact_3
- Set GPI_B-Mode to Prio
- Set Contact_4 to GPI_B
- Set Contact_5 to GPI_B

Pool A now consists of GPI 1, GPI 2 and GPI 3 (as take) in binary mode, controlling the up-converter preset. Pool B now consists of GPI 4 and GPI 5 in priority mode, controlling the audio presets. Pool A now works as follows:

Contact_1 status	Contact_2 status	Preset value (when Contact_3 (take) is closed)
0	0	Up-converter Preset 1
1	0	Up-converter Preset 2
0	1	Up-converter Preset 3
1	1	Up-converter Preset 4

Table 7 Pool value in binary mode

Pool B now works as follows:

Contact_4 status	Contact_5 status	Preset value
0	0	Audio Preset 1
1	0	Audio Preset 1
0	1	Audio Preset 2
1	1	Audio Preset 2 (because highest gets priority)

Table 8 Pool value in priority mode

Example 3: Two pools in priority mode

Let's say we would like to control the up-converter presets using Pool A (Up_CtrlA set to GPI_A) in priority mode and the audio presets using Pool B (Audio_Ctrl set to GPI_B) in priority mode. We could do the following settings:

- Set GPI_A-Mode to Prio
- Set Contact_1 to GPI_A
- Set Contact_2 to GPI_A
- Set GPI_B-Mode to Prio
- Set Contact_3 to GPI_B
- Set Contact_4 to GPI_B

Pool A now consists of GPI 1 and GPI 2 in a priority mode, controlling the Up converter preset. Pool B now consists of GPI 3 and GPI 4 in a priority mode, controlling the audio presets.

Pool A now works as follows:

Contact_1 status	Contact_2 status	Preset value
0	0	Up-converter Preset 1
1	0	Up-converter Preset 1
0	1	Up-converter Preset 2
1	1	Up-converter Preset 2 (because highest gets priority)

Table 9 Pool value in priority mode

Pool B now works as follows:

Contact_3 status	Contact_4 status	Preset value
0	0	Audio Preset 1
1	0	Audio Preset 1
0	1	Audio Preset 2
1	1	Audio Preset 2 (because highest gets priority)

Table 10 Pool value in priority mode



This product contains open-source software

This product contains open-source software licensed under the GNU Public License (GPL). A copy of the GNU Public License is included below. Under this license you are eligible to receive a copy of the source code of this software including any changes.

Axon Digital Design shall provide the source code on request either through physical distribution or electronic communication. For physical distribution you may be charged a fee that covers distribution costs. This offer is valid up to three years after date of purchase. Please direct your request to the support department of Axon Digital Design.

Axon Digital Design supports open-source software by participating in the development of open-source projects or submitting improvements to these projects. For more information see <http://opensource.axon.tv/>

GNU Public License version 2

TERMS AND CONDITIONS FOR COPYING, DISTRIBUTION AND MODIFICATION

0. This License applies to any program or other work which contains a notice placed by the copyright holder saying it may be distributed under the terms of this General Public License. The "Program", below, refers to any such program or work, and a "work based on the Program" means either the Program or any derivative work under copyright law: that is to say, a work containing the Program or a portion of it, either verbatim or with modifications and/or translated into another language. (Hereinafter, translation is included without limitation in the term "modification".) Each licensee is addressed as "you".

Activities other than copying, distribution and modification are not covered by this License; they are outside its scope. The act of running the Program is not restricted, and the output from the Program is covered only if its contents constitute a work based on the Program (independent of having been made by running the Program). Whether that is true depends on what the Program does.

1. You may copy and distribute verbatim copies of the Program's source code as you receive it, in any medium, provided that you conspicuously and appropriately publish on each copy an appropriate copyright notice and disclaimer of warranty; keep intact all the notices that refer to this License and to the absence of any warranty; and give any other recipients of the Program a copy of this License along with the Program.

You may charge a fee for the physical act of transferring a copy, and you may at your option offer warranty protection in exchange for a fee.

2. You may modify your copy or copies of the Program or any portion of it, thus forming a work based on the Program, and copy and distribute such modifications or work under the terms of Section 1 above, provided that you also meet all of these conditions:

- a) You must cause the modified files to carry prominent notices stating that you changed the files and the date of any change.
- b) You must cause any work that you distribute or publish, that in whole or in part contains or is derived from the Program or any part thereof, to be licensed as a whole at no charge to all third parties under the terms of this License.
- c) If the modified program normally reads commands interactively when run, you must cause it, when started running for such interactive use in the most ordinary way, to print or display an announcement including an appropriate copyright notice and a notice that there is no warranty (or else, saying that you provide a warranty) and that users may redistribute the program under these conditions, and telling the user how to view a copy of this License. (Exception: if the Program itself is interactive but does not normally print such an announcement, your work based on the Program is not required to print an announcement.)

These requirements apply to the modified work as a whole. If identifiable sections of that work are not derived from the Program, and can be reasonably considered independent and separate works in themselves, then this License, and its terms, do not apply to those sections when you distribute them as separate works. But when you distribute the same sections as part of a whole which is a work based on the Program, the distribution of the whole must be on the terms of this License, whose permissions for other licensees extend to the entire whole, and thus to each and every part regardless of who wrote it.

Thus, it is not the intent of this section to claim rights or contest your rights to work written entirely by you; rather, the intent is to exercise the right to control the distribution of derivative or collective works based on the Program.

In addition, mere aggregation of another work not based on the Program with the Program (or with a work based on the Program) on a volume of a storage or distribution medium does not bring the other work under the scope of this License.

3. You may copy and distribute the Program (or a work based on it, under Section 2) in object code or executable form under the terms of Sections 1 and 2 above provided that you also do one of the following:

- a) Accompany it with the complete corresponding machine-readable source code, which must be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,
- b) Accompany it with a written offer, valid for at least three years, to give any third party, for a charge no more than your cost of physically performing source distribution, a complete machine-readable copy of the corresponding source code, to be distributed under the terms of Sections 1 and 2 above on a medium customarily used for software interchange; or,



- c) Accompany it with the information you received as to the offer to distribute corresponding source code. (This alternative is allowed only for noncommercial distribution and only if you received the program in object code or executable form with such an offer, in accord with Subsection b above.)

The source code for a work means the preferred form of the work for making modifications to it. For an executable work, complete source code means all the source code for all modules it contains, plus any associated interface definition files, plus the scripts used to control compilation and installation of the executable. However, as a special exception, the source code distributed need not include anything that is normally distributed (in either source or binary form) with the major components (compiler, kernel, and so on) of the operating system on which the executable runs, unless that component itself accompanies the executable.

If distribution of executable or object code is made by offering access to copy from a designated place, then offering equivalent access to copy the source code from the same place counts as distribution of the source code, even though third parties are not compelled to copy the source along with the object code.

4. You may not copy, modify, sublicense, or distribute the Program except as expressly provided under this License. Any attempt otherwise to copy, modify, sublicense or distribute the Program is void, and will automatically terminate your rights under this License. However, parties who have received copies, or rights, from you under this License will not have their licenses terminated so long as such parties remain in full compliance.

5. You are not required to accept this License, since you have not signed it. However, nothing else grants you permission to modify or distribute the Program or its derivative works. These actions are prohibited by law if you do not accept this License. Therefore, by modifying or distributing the Program (or any work based on the Program), you indicate your acceptance of this License to do so, and all its terms and conditions for copying, distributing or modifying the Program or works based on it.

6. Each time you redistribute the Program (or any work based on the Program), the recipient automatically receives a license from the original licensor to copy, distribute or modify the Program subject to these terms and conditions. You may not impose any further restrictions on the recipients' exercise of the rights granted herein. You are not responsible for enforcing compliance by third parties to this License.

7. If, as a consequence of a court judgment or allegation of patent infringement or for any other reason (not limited to patent issues), conditions are imposed on you (whether by court order, agreement or otherwise) that contradict the conditions of this License, they do not excuse you from the conditions of this License. If you cannot distribute so as to satisfy simultaneously your obligations under this License and any other pertinent obligations, then as a consequence you may not distribute the Program at all. For example, if a patent license would not permit royalty-free redistribution of the Program by all those who receive copies directly or indirectly through you, then the only way you could satisfy both it and this License would be to refrain entirely from distribution of the Program.

If any portion of this section is held invalid or unenforceable under any particular circumstance, the balance of the section is intended to apply and the section as a whole is intended to apply in other circumstances.

It is not the purpose of this section to induce you to infringe any patents or other property right claims or to contest validity of any such claims; this section has the sole purpose of protecting the integrity of the free software distribution system, which is implemented by public license practices. Many people have made generous contributions to the wide range of software distributed through that system in reliance on consistent application of that system; it is up to the author/donor to decide if he or she is willing to distribute software through any other system and a licensee cannot impose that choice.

This section is intended to make thoroughly clear what is believed to be a consequence of the rest of this License.

8. If the distribution and/or use of the Program is restricted in certain countries either by patents or by copyrighted interfaces, the original copyright holder who places the Program under this License may add an explicit geographical distribution limitation excluding those countries, so that distribution is permitted only in or among countries not thus excluded. In such case, this License incorporates the limitation as if written in the body of this License.

9. The Free Software Foundation may publish revised and/or new versions of the General Public License from time to time. Such new versions will be similar in spirit to the present version, but may differ in detail to address new problems or concerns.

Each version is given a distinguishing version number. If the Program specifies a version number of this License which applies to it and "any later version", you have the option of following the terms and conditions either of that version or of any later version published by the Free Software Foundation. If the Program does not specify a version number of this License, you may choose any version ever published by the Free Software Foundation.

10. If you wish to incorporate parts of the Program into other free programs whose distribution conditions are different, write to the author to ask for permission. For software which is copyrighted by the Free Software Foundation, write to the Free Software Foundation; we sometimes make exceptions for this. Our decision will be guided by the two goals of preserving the free status of all derivatives of our free software and of promoting the sharing and reuse of software generally.



NO WARRANTY

11. BECAUSE THE PROGRAM IS LICENSED FREE OF CHARGE, THERE IS NO WARRANTY FOR THE PROGRAM, TO THE EXTENT PERMITTED BY APPLICABLE LAW. EXCEPT WHEN OTHERWISE STATED IN WRITING THE COPYRIGHT HOLDERS AND/OR OTHER PARTIES PROVIDE THE PROGRAM "AS IS" WITHOUT WARRANTY OF ANY KIND, EITHER EXPRESSED OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, THE IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR A PARTICULAR PURPOSE. THE ENTIRE RISK AS TO THE QUALITY AND PERFORMANCE OF THE PROGRAM IS WITH YOU. SHOULD THE PROGRAM PROVE DEFECTIVE, YOU ASSUME THE COST OF ALL NECESSARY SERVICING, REPAIR OR CORRECTION.

12. IN NO EVENT UNLESS REQUIRED BY APPLICABLE LAW OR AGREED TO IN WRITING WILL ANY COPYRIGHT HOLDER, OR ANY OTHER PARTY WHO MAY MODIFY AND/OR REDISTRIBUTE THE PROGRAM AS PERMITTED ABOVE, BE LIABLE TO YOU FOR DAMAGES, INCLUDING ANY GENERAL, SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES ARISING OUT OF THE USE OR INABILITY TO USE THE PROGRAM (INCLUDING BUT NOT LIMITED TO LOSS OF DATA OR DATA BEING RENDERED INACCURATE OR LOSSES SUSTAINED BY YOU OR THIRD PARTIES OR A FAILURE OF THE PROGRAM TO OPERATE WITH ANY OTHER PROGRAMS), EVEN IF SUCH HOLDER OR OTHER PARTY HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES.